


AD-A180 000


A FREEZE-THAW TEST TO DETERMINE THE FROST
SUSCEPTIBILITY OF SOILS(U) COLD REGIONS RESEARCH AND
ENGINEERING LAB HANOVER NH E J CHAMBERLAIN JAN 87
CRREL-SR-87-1 DOT/FAA/PM-85/20 F/G 8/10

1/1

UNCLASSIFIED

NL





MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS-1963-A

DTIC FILE COPY



12

**US Army Corps
of Engineers**

Cold Regions Research &
Engineering Laboratory


Special Report 87-1

January 1987

AD-A180 000

A freeze-thaw test to determine the frost susceptibility of soils

Edwin J. Chamberlain



Prepared for
OFFICE OF THE CHIEF OF ENGINEERS
FEDERAL AVIATION ADMINISTRATION
FEDERAL HIGHWAY ADMINISTRATION

Approved for public release; distribution is unlimited.

87

5 11 004

For conversion of SI metric units to U.S./British customary units of measurement consult ASTM Standard E380, Metric Practice Guide, published by the American Society for Testing and Materials, 1916 Race St., Philadelphia, Pa. 19103.

Unclassified

SECURITY CLASSIFICATION OF THIS PAGE

REPORT DOCUMENTATION PAGE

Form Approved
OMB No 0704-0188
Exp Date Jun 30 1986


1a REPORT SECURITY CLASSIFICATION Unclassified			1b. RESTRICTIVE MARKINGS		
2a SECURITY CLASSIFICATION AUTHORITY			3. DISTRIBUTION/AVAILABILITY OF REPORT Approved for public release; distribution is unlimited.		
2b DECLASSIFICATION/DOWNGRADING SCHEDULE					
4 PERFORMING ORGANIZATION REPORT NUMBER(S) Special Report 87-1			5. MONITORING ORGANIZATION REPORT NUMBER(S) DOT/FAA/PM-85/20		
6a. NAME OF PERFORMING ORGANIZATION U.S. Army Cold Regions Research and Engineering Laboratory		6b. OFFICE SYMBOL (If applicable) CRREL	7a. NAME OF MONITORING ORGANIZATION Federal Aviation Administration Program Engineering and Maintenance Service		
6c. ADDRESS (City, State, and ZIP Code) 72 Lyme Road Hanover, N.H. 03755-1290			7b. ADDRESS (City, State, and ZIP Code) Washington, D.C. 20591		
8a. NAME OF FUNDING/SPONSORING ORGANIZATION See 16.		8b. OFFICE SYMBOL (If applicable)	9. PROCUREMENT INSTRUMENT IDENTIFICATION NUMBER FHWA 8-3-0187		
8c. ADDRESS (City, State, and ZIP Code)			10. SOURCE OF FUNDING NUMBERS		
			PROGRAM ELEMENT NO. 6.27.30A	PROJECT NO. 4A762 730AT42	TASK NO A2, A3
					WORK UNIT ACCESSION NO 002 006
11. TITLE (Include Security Classification) A Freeze-thaw test to determine the frost susceptibility of soils					
12. PERSONAL AUTHOR(S) Chamberlain, Edwin J.					
13a. TYPE OF REPORT Final		13b. TIME COVERED FROM _____ TO _____		14. DATE OF REPORT (Year, Month, Day) January 1987	
15. PAGE COUNT 94					
16. SUPPLEMENTARY NOTATION Co-sponsored by Federal Aviation Administration, Washington, D.C.; Federal Highway Administration, Washington, D.C.; and Office of the Chief of Engineers, Washington, D.C.					
17. COSATI CODES			18. SUBJECT TERMS (Continue on reverse if necessary and identify by block number)		
FIELD	GROUP	SUB-GROUP	Airfields ; Pavement design ;		
			Frost-susceptible soils ; Roads		
			Frost susceptibility test		
19. ABSTRACT (Continue on reverse if necessary and identify by block number) A new freezing test for determining the frost susceptibility of soils is presented to supplant the standard CRREL freezing test currently specified by the Corps of Engineers. This test reduces the time required to determine the frost susceptibility of a soil in half. It also allows for the determination of both the frost heave and thaw weakening susceptibilities and considers the effects of freeze-thaw cycling. The new freezing test eliminates much of the variability in test results caused by the human element by completely automating the temperature control and data observations.					
20. DISTRIBUTION/AVAILABILITY OF ABSTRACT <input checked="" type="checkbox"/> UNCLASSIFIED/UNLIMITED <input type="checkbox"/> SAME AS RPT <input type="checkbox"/> DTIC USERS			21. ABSTRACT SECURITY CLASSIFICATION Unclassified		
22a. NAME OF RESPONSIBLE INDIVIDUAL E.J. Chamberlain			22b. TELEPHONE (Include Area Code) 603-646-4100		22c. OFFICE SYMBOL CRREL-EA

PREFACE

This report was prepared by Edwin J. Chamberlain, Jr., Research Civil Engineer, Applied Research Branch, Experimental Engineering Division, U.S. Army Cold Regions Research and Engineering Laboratory. Funding was provided by the Federal Highway Administration and the Federal Aviation Administration under Order No. FHWA 8-3-0187, Full-Scale Tests to Evaluate Frost Action Predictive Techniques, and by DA Project 4A762730AT42, Design, Construction and Operations Technology for Cold Regions; Task A2, Soils and Foundations Technology in Cold Regions; Work Unit 002, Seasonal Changes in Strength and Stiffness of Soils and Base Courses; and Task A3, Facilities Technology for Cold Regions; Work Unit 006, Volume Change Induced by Freezing and Thawing of Pavement Systems.

Members of the Board of Consultants reviewing this study are Dr. B.J. Dempsey, University of Illinois; Dr. D.G. Fredlund, University of Saskatchewan; Dr. M.E. Harr, Purdue University; E. Penner, National Research Council of Canada; and Dr. M.W. Witczak, University of Maryland. Special recognition is due R. Roberts for his assistance with the test program. The author also thanks H. Tomita and D. Carbee for reviewing the report.

The contents of this report are not to be used for advertising or promotional purposes. Citation of brand names does not constitute an official endorsement or approval of the use of such commercial products.



CONTENTS

	Page
Abstract.....	1
Preface.....	11
1. Introduction.....	1
2. Current freezing test practice in the Corps of Engineers.....	1
3. Limitations of the standard freezing test.....	5
4. Development of a new freezing test.....	6
5. Description of the freezing test.....	7
5.1 Apparatus.....	7
5.2 Data acquisition and control system.....	10
5.3 Freeze-thaw test.....	11
6. Setting up the test.....	14
6.1 Initial setup procedures.....	14
6.2 Sample preparation.....	18
6.3 Freezing point determination.....	20
6.4 Final setup procedures.....	21
7. Conducting the test.....	24
7.1 Loading the running programs.....	24
7.2 Starting the test.....	26
7.3 Nucleation.....	28
7.4 Observing the test.....	28
7.5 Completing the test.....	29
7.6 Conducting the CBR test after thawing.....	30
7.7 Presenting the data.....	31
7.8 Determining the frost susceptibility.....	31
8. Discussion of test results.....	33
9. Conclusions.....	34
10. Literature cited.....	35
Appendix A: Assembling the apparatus.....	37
Appendix B: Data acquisition and control system.....	39
Appendix C: Program listings.....	45
Appendix D: Data sheets for recording and presenting results.....	89

ILLUSTRATIONS

Figure

- | | |
|---|---|
| 1. Inside-tapered freezing cell for confining the test sample
in the CRREL standard freezing test..... | 2 |
| 2. Cutaway view of the freezing cabinet for the CRREL standard
freezing test..... | 3 |

3. Typical results from the CRREL standard freezing test.....	4
4. Sample assembly for the new freezing test.....	8
5. Freeze cabinet assembly for the new freezing test.....	9
6. Complete setup for the new freezing test.....	10
7. Schematic for the data acquisition and control system.....	11
8. Boundary temperatures for the new freezing test.....	12
9. Example of thermocouple calibration printout.....	16
10. Compaction mold assembly.....	19
11. Setup for determining the pore water freezing temperature.....	20
12. Selecting the freezing point depression from the cooling curve.....	21
13. Location of thermocouples in the sample.....	23
14. Flow chart for data acquisition and temperature control program.....	25
15. Example of test results for a single scan.....	27
16. Example of summary printout at the end of a test.....	30
17. Example of the effect of freezing and thawing on frost heave rate.....	32
18. Correlation of laboratory and field frost heave rates.....	33
19. Comparison of laboratory CBR test results after freezing and thawing with field pavement deflection.....	33

TABLES

Table

1. Frost susceptibility classification according to the standard CRREL freezing test.....	5
2. Boundary temperature conditions for the new freeze test.....	12
3. Tentative frost susceptibility criteria for the new freeze- thaw test.....	32

A FREEZE-THAW TEST TO DETERMINE THE FROST SUSCEPTIBILITY OF SOILS

Edwin J. Chamberlain

1. INTRODUCTION

Laboratory freezing tests are necessary to accurately characterize the frost susceptibility of soils. This is especially true for borderline granular materials used for the base and subbase layers in roads and runways.

The Corps of Engineers has employed a freezing test (Chamberlain and Carbee 1981) for more than 30 years. While this freezing test has proven adequate to identify and classify frost-susceptible soils, it suffers from several serious defects. Most significant of these are poor temperature control, indeterminate side friction, lengthy test period, lack of thaw weakening index, and provision for only a single freeze. Furthermore, correlation of the laboratory results with field performance is undocumented and the test appears to be overly conservative.

In a review of frost susceptibility index testing (Chamberlain 1981), the author concluded that no other available freezing test fulfilled current requirements for performance, efficiency and reliability. A new freezing test was needed, one that would address the deficiencies and draw upon current advances in test automation technology.

This report discusses the current Corps of Engineers practice for conducting freezing tests on soils, describes a new freezing test designed to replace it, outlines in detail test equipment and procedures, and suggests a method of classifying the frost susceptibility of soils based on both frost heave and thaw weakening. A companion report (Chamberlain 1986) discusses the selection process for this new freezing test in greater detail. Details on the automation of the test have also been reported elsewhere (Chamberlain 1984).

2. CURRENT FREEZING TEST PRACTICE IN THE CORPS OF ENGINEERS

The frost heave test employed by the Corps of Engineers was developed for evaluating the relative frost susceptibility of soils and granular base materials. It is often referred to as the CRREL freezing test. In this

report it will be called the CRREL standard freezing test in deference to its long-standing use. Details of the test were first published by Haley and Kaplar (1952) and a comprehensive summary of test procedures and results was given later by Kaplar (1974). More recently, Chamberlain and Carbee (1981) described the current state of this freezing test.

In the standard test, materials are subjected to a very severe combination of freezing, moisture, and surcharge conditions that are conducive to frost heaving. The results do not quantitatively predict the actual magnitude of frost heave under field conditions, but they are designed to provide a relative indication of the potential for frost heave.

Soil samples are generally compacted to densities equivalent to AASHTO T 180-57, saturated, and frozen from the top down at a constant rate of frost penetration of approximately 1.3 cm/day for 12 days. The samples are frozen in tapered, cast acrylic cylinders that are Teflon-lined and lightly coated with silicone grease (Fig. 1) to reduce side friction. A porous stone at the base and a constant-head water supply are used to pro-




Figure 1. Inside-tapered freezing cell for confining the test sample in the CRREL standard freezing test (from Kaplar 1974).




Figure 2. Cutaway view of the freezing cabinet for the CRREL standard freezing test (from Kaplar 1974).

vide a source of water 1 cm above the sample bottom. A surcharge of 3.5 kPa is placed on the sample to simulate 15 cm of asphalt concrete pavement. The samples are frozen in groups of four in a freezing cabinet (Fig. 2). The lower boundary air temperature is maintained at 4°C throughout the test while the upper boundary air temperature is lowered daily in steps to facilitate an average frost penetration rate of 1.3 cm/day.

The temperatures in the soil samples are measured by thermocouples placed through the cell walls and are automatically recorded by a data acquisition system. Frost heave is observed with linear motion potentiometers and continuously recorded, along with the thermocouple outputs, on the data acquisition system.

Frost depths are manually determined by plotting the temperature profiles and interpolating the position of the 0°C isotherm. The frost heave rate is determined from a plot of the heave versus time as the maximum rate occurring during the test period. Figure 3 shows typical results.




Figure 3. Typical results from the CRREL standard freezing test (from Kaplan, 1974).

Table 1. Frost susceptibility classification according to the standard CRREL freezing test.

<u>Frost susceptibility</u>	<u>Average rate of heave (mm/day)</u>
Negligible	0-0.5
Very low	0.5-1.0
Low	1.0-2.0
Medium	2.0-4.0
High	4.0-8.0
Very high	> 8.0

The frost susceptibility classification is obtained from Table 1 using the maximum heave rate determined from the freezing test.

3. LIMITATIONS OF THE STANDARD FREEZING TEST

The standard CRREL frost heave test has several limitations. The test is long (12 days) and is encumbered by the frequent temperature adjustments necessary to maintain the constant frost-penetration rate. And if samples of different thermal properties are tested together, the rate of frost penetration cannot be kept equal in each. There is also a problem with side friction, particularly with coarser grained materials. The test does not consider the effects of freeze-thaw cycling. Also, the test is principally an index test for frost heave and does not directly address thaw weakening, which is frequently more of a problem than frost heave. Finally, the test is very conservative and probably rejects many materials that would prove to be non-frost-susceptible under field conditions.

Most of these problems have been recognized for a number of years. As a result, a recent report (Chamberlain 1981) recommended that a new test be developed to address these problems. The report suggested that a new method be developed to eliminate side friction (possibly by using stacked rings), that constant temperature boundary conditions be employed with at

least two freeze-thaw cycles, and that a California Bearing Ratio (CBR) test be conducted after the last thaw to determine thaw weakening characteristics.

4. DEVELOPMENT OF A NEW FREEZING TEST

The new freezing test was designed to alleviate the problems previously mentioned. As a result, the following objectives were established:

- a. The test should be as simple as possible so that highway and geotechnical laboratories could readily conduct the test and obtain reproducible results. Complexities in the test should be diminished by automating the test as much as possible.
- b. The test equipment must be reliable.
- c. The test must be of short duration.
- d. The test must accommodate the complete range of material types; in particular, it must accommodate granular base and subbase materials as well as fine-grained subgrade materials.
- e. The test apparatus should be relatively inexpensive to construct and operate.
- f. The test must relate to frost heave and thaw weakening in the field.
- g. The test should be readily modified so that actual field conditions could be simulated if desired.

Several of the test parameters critical to satisfying these objectives were developed. They include:

- a. Controlling the boundary temperatures precisely.
- b. Minimizing radial heat flow.
- c. Minimizing side friction.
- d. Providing free access to water.
- e. Allowing for freeze-thaw cycling.
- f. Accounting for both frost heave and thaw weakening.
- g. Limiting the test to 1 week.

The literature on freezing tests was thoroughly reviewed for state of the art practices. In addition, the author was able to draw upon his considerable experience in conducting soils freezing tests. As a result, it was proposed that the new freezing test include the following features:

a. The basic cell should be of the multi-ring type with a rubber membrane liner.

b. The upper and lower boundary temperatures should be controlled by circulating liquid from programmable, refrigerated circulating baths through heat exchange plates.

c. A temperature controlled cabinet or room capable of maintaining an ambient temperature of 1°C for four samples should be included.

d. The samples should have fixed surcharges.

e. A constant-head source of water fixed at the bottom of the samples should be available.

f. The test would employ two freeze-thaw cycles of 2 days duration each.

g. The test should use heave rate as an index of frost heave susceptibility.

h. The CBR test should be used as an index of thaw weakening susceptibility.

i. The entire test should be automated through a computerized data acquisition and temperature control system.

A completion discussion of the development process for the new freezing test is given by Chamberlain (1986).

5. DESCRIPTION OF THE FREEZING TEST

5.1 Apparatus

The new freezing test imposes freeze-thaw cycling on four samples, 150 mm (6 in.) in diameter, and 150 mm (6 in.) in height. The samples are confined in containers made up of Plexiglas rings lined with rubber membranes. Water is freely available through porous base plates. Figure 4 illustrates the arrangement.

Cold plates are located directly on top of the samples and beneath the porous bases. The top and base plates are connected in series in two separate circuits. Ethylene glycol-water solutions are circulated through the cold plates from two refrigerated circulating baths to control the end temperatures. Bath 1 is connected to the top plate circuit, bath 2 to the base plate circuit.

A surcharge of 3.5 kPa (0.5 lb/in.²) is placed on top of the upper cold plate to simulate the weight of a 150-mm (6-in.) thick asphalt con-





Figure 4. Sample assembly for the new freezing test.

crete pavement surface. A dial gauge and a Direct Current Differential Transformer (DCDT) are arranged on top to follow the frost heave and thaw settlement. Thermocouples are placed into the side of the sample to allow the freezing process to be followed.


Each sample is provided with a constant-head water supply that provides a controlled source of water during freezing, and which also provides a means for saturating the samples before freezing.

Four samples can be tested at the same time in the modified freezer chest (Fig. 5). The freezer chest provides an ambient temperature just above the freezing point of water so that radial heat flow is minimized.

The entire freezing and thawing process and the data gathering are accomplished automatically through the use of an inexpensive data acquisition and control system. Figure 6 illustrates the entire test setup. Details on assembling all the parts of this setup are given in Appendix A.



PLAN VIEW



PROFILE

Figure 5. Freeze cabinet assembly for the new freezing test (A = sample assembly, B = water supply, C = rigid insulation, D = loose insulation, E = air space for temperature control, F = heat source, G = fan, H = thermocouple and DCDT output panel, I = temperature control unit, J = electrical leads to data logger, K = circulation lines from top cold plate to refrigerated circulating bath, L = circulation lines from bottom cold plate, M = freezer chest, N = drainage lines).




Figure 6. Complete setup for the new freezing test.

5.2 Data acquisition and control system

The data acquisition and control system consists of a computer controller, a data acquisition and control unit, a thermal printer and a digital cassette drive (Fig. 7).

The data acquisition unit is set up for making 36 single-ended dc-voltage readings from the thermocouples and 5 double-ended dc-voltage readings from the four DCDTs and the single power supply. Circuit diagrams showing the thermocouple and DCDT connections to the data logger are given in Appendix B, as are the data logger multiplexer card settings.

Two channels are dedicated to controlling the temperatures of the circulating baths. The two channels allow the selection of one of four pairs of set point temperatures in the refrigerated baths. Details on this are also given in Appendix B.

The data acquisition and control unit is controlled with a small, hand-held computer (an HP41CX calculator). All the necessary programs are stored on a tape cassette and are readily accessed by the computer from the cassette drive. The cassette drive also provides a storage medium for the data accessed during the test.

The computer has a built-in time base that is used to control the sequence of data taking and temperature cycling. Programs are provided to test the setup and calibrate the thermocouples before freezing, and to take and reduce the data during the test and to provide the temperature control. Annotated listings of the programs are provided in Appendix C. The thermal printer provides a hard copy of all the reduced data.

The entire system is battery operated, but is set up to operate normally on line voltage. Short-term power failures will not affect the




Figure 7. Schematic for the data acquisition and control system.

data acquisition and control process (power failures will, however, affect the operation of the refrigerated circulating baths and the freezing cabinet).

5.3 Freeze-thaw test

This test imposes two freeze-thaw cycles on the four samples placed in the freezer chest. Each leg of the two freeze-thaw cycles requires 1 day. The entire freeze-thaw cycling program requires 5 days, including an initial day of conditioning. Table 2 and Figure 8 show the boundary temperature settings during the freeze-thaw cycling period.

Each freezing leg consists of two different boundary temperature conditions. The first 8 hours of freezing is accomplished with an upper cold plate temperature of -3°C and a lower cold plate temperature of 3°C . The next 16 hours of the 24-hour freeze period is run with boundary tempera-

Table 2. Boundary temperature conditions for the new freeze test.

Day	Elapsed* time (hr)	Bath 1 (top temp.) (°C)	Bath 2 (bot. temp.) (°C)	Temperature selector position†
1	0	12	13	T_2
	16	3	3	T_0
2	24	-3	3	Bath
	32	-12	0.0	T_1
3	48	12	3	T_2
	64	3	3	T_0
4	72	-3	3	Bath
	80	-12	0.0	T_1
5	96	12	3	T_2
	112-120.5	3	3	T_0

*After running program has been started.

†For manual operation and making temperature adjustments.




Figure 8. Boundary temperatures for the new freezing test.

tures of -12° and 0.0°C . The purpose of this freezing method is to impose freezing rates that are similar to those that occur naturally within a normal work day and to completely freeze the samples within 24 hours.

Complete freezing is necessary to thoroughly condition the material with frost action prior to freezing it a second time. The heave rates for materials containing clay fines may be increased significantly by freeze-thaw cycling. This procedure is designed to reveal any sensitivity of the frost heave rate to repeated freezing and thawing.

The thawing legs of the freeze-thaw cycles begin with the upper boundary temperature fixed at 12°C and the lower boundary temperature set at 3°C . After 16 hours, the upper boundary temperature is lowered to 3°C and both ends are held at 3°C for the remainder of the 24-hour thaw period. These thaw period boundary temperatures were selected to ensure the complete thawing of the frozen samples. The same boundary temperatures are applied during the conditioning period preceding the first freeze. The purpose of doing this is to ensure identical temperature profiles within the samples prior to both freeze legs.

Because of time constraints, only two freeze-thaw cycles are imposed. To make this test more readily acceptable, the time allowed for freezing and thawing is restricted to 1 week. Additional freeze-thaw cycling would be only of use in clay soils as most of the changes in structural properties that affect heave rate occur during the first freeze in most other soils.

Frost heave rates after 8 hours into each freezing leg are labeled critical heave rates and are used to determine the frost heave susceptibility of the material. Details on how to determine the frost susceptibility are given later in this report.

After the second thaw, the test samples are subjected to the CBR test and are sliced to determine moisture content profiles. The CBR test data are used to determine the thaw weakening susceptibility.

The overall frost susceptibility determination is based on an analysis of all the heave rate and thaw CBR data and knowledge of specific site conditions.

6. SETTING UP THE TEST

6.1 Initial setup procedures

The computer programs (Appendix C) used during the setup procedures allow the scanning of the thermocouple (T/C) assemblies both to determine that they are functioning properly and to calibrate each T/C for zero shift. These programs also allow the scanning of the frost heave transducers (DCDTs) for proper functioning and the circulating bath temperatures for proper settings. One of these programs is also used to initialize a cassette tape for recording the test data.

6.1.1 Loading the setup programs

- a. Place the cassette marked NEW FREEZE in the cassette drive, label side up and tape end in first.
- b. Turn on the cassette drive to STANDBY mode.
- c. Turn on the thermal printer to STANDBY and MANUAL modes.
- d. Turn on the data logger and computer.
- e. Clear memory by pressing +/ON .
- f. Load the setup programs into the computer by pressing the following key sequence:

(1) α FRI α .

(2) XEQ α READP α .

The setup programs will be automatically loaded. Approximately 1 minute and 10 seconds is required. Wait for the display to show the numerical configuration before proceeding.

6.1.2 Adjusting the reference junction

- a. Make a reference temperature ice bath in a thermos bottle with crushed ice and distilled water. Make sure that the crushed ice completely fills the thermos bottle before filling it with water.
- b. Bundle all 36 thermocouples and the REF thermocouple together with rubber bands and insert them approximately 3 cm deep into the ice bath. Care should be taken to make sure that the tips of all thermocouples are within 1 cm of each other.
- c. Wait approximately 30 minutes for the temperature to equilibrate.
- d. Execute the program to set the reference junction by pressing the keys:

(1) USER on.

(2) Σ +

- e. The average reading for the thermocouples will be printed out.
- f. Adjust the trim pot on the reference junction to increase (counterclockwise) or decrease (clockwise) the average reading.
- g. Repeat steps d through g until the average reading is within $\pm 0.03^{\circ}\text{C}$.

6.1.3 Calibrating the thermocouples

a. Calibrate the T/Cs after the reference junction has been properly adjusted.

b. Make sure that the ice bath is fresh.

c. Execute the thermocouple calibration program by pressing the following key sequence:

(1) USER on.

(2) LN.

d. You will be prompted for the following information:

(1) SERIES NAME?

(2) SAMPLE 1 NAME?

(3) SAMPLE 2 NAME?

(4) SAMPLE 3 NAME?

(5) SAMPLE 4 NAME?

} Respond with a six digit
alpha-numeric name followed by
the R/S key for each question.

(6) NO. OF SCANS?

Enter 6 followed by R/S.

(7) SCAN INT?

Scan interval in HH.MMSS format
followed by R/S; defaults to
30 minutes if only R/S is pressed.

(8) START DATE?

Enter date in MM.DDYYYY format
followed by R/S; defaults to
current date if only R/S is pressed.

(9) START TIME?

Enter time in HH.MMSS format
followed by R/S; defaults to
current time plus 10 seconds if
only R/S is pressed.

e. Wait for the desired number of scans to be completed. Upon completion of six scans, the readings for each T/C will be averaged and stored in the file TSAVE2 in the extended memory of the HP41CX calculator (computer). A copy of each scan and the average values will be printed on the thermal printer. An example is shown in Figure 9.

TIME= 11:10
 DATE= 19.01.80
 MAIN POST
 TP 222
 AVG TC ZEPDS

BERG1

TP-1

DEPTH MM	TEMP DEG C
0.00	0.04
12.70	-4.39
38.10	0.04
63.50	-0.04
88.90	4.33-03
114.30	4.33-03
139.70	0.01
152.40	-0.06

MP-1

DEPTH MM	TEMP DEG C
0.00	-0.07
12.70	-4.39-03
38.10	-4.04
63.50	0.32
88.90	-0.05
114.30	-0.32
139.70	0.01
152.40	0.01

TP-2

DEPTH MM	TEMP DEG C
0.00	-0.07
12.70	-4.03
38.10	-1.02
63.50	-0.05
88.90	-0.04
114.30	-0.05
139.70	0.01
152.40	-0.04

MP-2

DEPTH MM	TEMP DEG C
0.00	0.06
12.70	0.03
38.10	-0.02
63.50	-0.03
88.90	-4.33-03
114.30	4.33-03
139.70	0.01
152.40	-0.02

COLD BATH= 0.04 DEG C
 WARM BATH= 0.02 DEG C
 AMBIENT= 0.01 DEG C
 ICE BATH= -4.39-03 DEG C

END OF READING

Figure 9. Example of thermocouple calibration printout.

6.1.4 Initializing the tape cassette

It is important that the tape cassette be initialized only after the thermocouples have been calibrated because the SERIES NAME entered during the calibration procedure is used as the DATA FILE NAME on the tape. Initialize the tape as follows:

- Place a fresh tape cassette in the cassette drive.
- Press XEQ α NEWM α.
- Respond to the prompt NEWM _ _ _ by pressing 001 (establishes space for one file); wait 3.5 minutes for completion of this operation.
- Press USER on.
- Press the 1/x key (establishes 16,000 data spaces on the cassette).
- Wait about 10 minutes for completion of this operation.
- Remove this tape, mark it with series name and place it in the storage compartment of the cassette drive.

6.1.5 Checking the bath temperatures

a. Temporarily connect together the two circulation lines from the cold bath with a straight connector.

b. Ensure that the bath thermocouples are in the adaptors in the outlet lines located just inside the freezer compartment. Use silicone rubber to seal.

c. Make sure that there is sufficient 50/50 ethylene glycol-water solution in each refrigerated bath to fill each reservoir to within 25 mm (1 in.) of the top of the unit.

d. Turn on the power and cooling system switches on each bath and put the local/remote switches in the local positions. Set main dial temperature to 0°C. When the heater lights begin to flicker, the set temperature is being controlled.

e. For systems with hand set temperature control:

(1) Set coarse dial to 3°C on both baths. When the heater lights flicker, make a scan of the bath temperatures by pressing:

(a) USER on.

(b) \sqrt{X} Key.

Make adjustments to the coarse and fine dials until the temperature is obtained to within $\pm 0.1^\circ\text{C}$ of $+3^\circ\text{C}$.

(2) Repeat procedure (1) during the freeze-thaw test to obtain the appropriate bath temperatures. Make fine adjustments every 15 minutes until the appropriate temperature is obtained.

f. For systems with set point temperatures located on the baths:

(1) Set the temperature selector switches to DIAL. Set the main dials to the appropriate temperatures as shown in Table 2. When the heater lights flicker, make a scan of the bath temperatures by pressing:

(a) USER on.

(b) \sqrt{X} Key.

Make adjustments to the coarse and fine dials until the desired temperature is obtained to within $\pm 0.1^\circ\text{C}$. Table 2 shows the correct temperature settings.

g. Repeat this procedure for each of the other three pairs of set temperatures, T_0 , T_1 and T_2 , using a fine screwdriver to make necessary adjustments to the small, slotted temperature-control potentiometers.

h. Do not use the fine temperature control to adjust the main dial temperature after T_0 , T_1 and T_2 are set. The fine dial setting also affects T_0 , T_1 and T_2 . Use only the coarse dial to make further dial temperature adjustments.

6.2 Sample preparation

Because large-diameter undisturbed samples of soil and gravel materials are difficult to obtain, test samples are normally compacted in the laboratory to in situ density conditions. It is, thus, desirable to know the moisture and density characteristics of the subject materials before preparing the sample. With that understanding, the sample preparation procedure is as follows.

6.2.1 Data sheets

Prepare data sheets such as shown in Appendix D. Fill in all of the data, including the sample identification, sample specifications and the compaction mode.

6.2.2 Materials

Weigh out approximately 6000 g of the soil. It is not necessary to dry the soil first unless the water content is greater than desired. Mix well and determine the water content on a 100-g sample. Adjust the moisture content of the remaining material to the desired value and allow the sample to condition overnight in a closed container.

6.2.3 Molds

Select six Plexiglas rings and a rubber membrane. Make sure that two of the rings have grooves cut into one edge. Tape the splits tightly closed with filament tape. Stretch the rubber membrane and make sure that there are no holes or defects. Weigh the rings, membrane and the Plexiglas base disk together and record the results.

While the material is conditioning, set up the sample mold. First, place one of the three steel side plates into the cavity on the steel base plate. The tops of the side plates are marked "T." Next, place the Plexiglas base plate with a rubber membrane wrapped around it into the bottom of the mold. The rubber membrane should lie collapsed on top of the Plexiglas base. Then, place a second side plate on the base, fitting it snugly against the first. Next, place the Plexiglas rings into the mold, one at a time. The thermocouple holes in the rings must be aligned vertically. The

top and bottom rings have grooves cut in them to accommodate thermocouples at the sample ends. These grooves must be positioned facing the ends. The mold assembly should now look as shown in Figure 10. After the six rings are in place, position the last side plate in place and bolt on the top steel plate. Pull up the rubber membrane and stretch it out at the top of the assembly and down over the corners of the top plate. Make sure that the membrane is tight and free of ripples. You are now ready to compact the sample.




Figure 10. Compaction mold assembly.

6.2.4 Compaction

The test material is placed into the mold and compacted in five layers of equal thickness. The amount of soil and compaction effort will be determined by the dry density that you want. A modified Proctor hammer is preferred because the guide tube protects the rubber membrane from compaction damage. During compaction, make a water content determination on a 100-g subsample. Enter the information on the data sheet. Compact the sample level with the top of the uppermost ring. Fold up the rubber membrane and remove the compacted sample assembly from the steel mold.

6.2.5 Sample property determination

Weigh the sample, including the Plexiglas rings, the rubber membrane and the Plexiglas base. Enter the information on the data sheet and make calculations of the wet and dry unit weights, void ratio, porosity and degree of saturation.

6.3 Freezing point determination

The freezing point of the pore water in soils is commonly just below 0°C . However, fine-grained soils and coarser-grained soils containing salts may have lower freezing points. The freezing point can be determined by placing a thermocouple in a small amount of test material in a test tube and observing the temperature changes during freezing. The soil should be placed in the test tube at a water content that is equivalent to 90 to 95% saturation for the selected dry density. Figure 11 illustrates the arrangement. Cold bath 1 can be used to induce freezing. Use the following procedure:

- Set the cold-bath-1 temperature selector switch to the bath position (-3°C) and local/remote switch to local.
- Fill a clean test tube with 1 cm of wet soil and press.
- Center the thermocouple and press another 1 cm of soil around it.
- Immerse the test tube in the -3°C ethylene-glycol solution.
- Observe temperature with time.
- Record the steady-state freezing point depression temperature that occurs after nucleation (Fig. 12).




Figure 11. Setup for determining the pore water freezing temperature.




Figure 12. Selecting the freezing point depression from the cooling curve.

g. Thaw the sample, remove the thermocouple and determine the soil water content.

h. Place the thermocouple in the ice bath and read the temperature.

i. Subtract the ice bath reference temperature from the measured freezing point depression temperature to obtain the adjusted freezing point depression.

The freezing point depression temperature obtained with this procedure is used for two purposes. The first is to allow the set point temperatures of the refrigerated bath to be adjusted. If the freezing point depression is lower than -0.5°C , then the cold-side temperatures should be lowered by the amount of the freezing point depression. For example, if the freezing point depression is -1°C , then T_{BATH} on refrigerated bath 1 should be lowered to -4°C and T_1 to -13°C . The freezing point depression is also used to estimate the position of the freezing isotherm and is input into the running program when the FREEZE TEMP? prompt appears.

6.4 Final setup procedures

6.4.1 Mounting the samples

Roll the rubber membrane over the outside of the Plexiglas rings at both ends of the sample assembly. Place a piece of thin plastic film (Saran wrap) and a Plexiglas disk over the top end to prevent evaporation. Place a piece of filter paper on the porous stainless steel disk in the

base assembly, and position the sample on the base so that the thermocouple holes are located on the surface farthest away from the post that carries the dial gauge and DCDT. Roll down the rubber membrane over the base and seal with heavy rubber bands or O-rings (Fig. 4).

6.4.2 Placing the samples in the freezer

Position each of the sample assemblies atop of the cooling plates located at the bottom of the freeze compartment so that the posts are located in the corners and the thermocouple holes are located toward the center of the box. Figure 5 shows the sample numbering order. Record the location of each sample. Connect the inlet and outlet water lines to each sample base. Place a surcharge weight on top of each sample.

6.4.3 Preparing the saturation

Make sure that the inlet and outlet water lines for each sample are clamped off. Fill the water supply tubes with water (preferably distilled water) and position the top caps with the long bubble tubes attached. A little vacuum grease will ensure a good seal. Loosen the brass nut sealing the bubble tube and lower it until the tape mark is flush with the top of the fitting. Clamp the small-diameter drain line located on the outside left side of the freezer and open both the inlet and outlet clamps on the water lines leading to and from the samples. Disconnect the small-diameter drain line from the T-connector located on the side of the freezer, open the clamp and allow water to drain into a dish or pan until air is completely purged from the system. Close the clamp and reconnect the drain line to the T-connector. The water pressure level is now at approximately 25 mm (1 in.) above the base (both the bottom end of the bubble tube and open end of the T-connector are at this level). Repeat this procedure for each sample. You are now ready to saturate.

6.4.4 Saturating the samples

Begin saturation at the start of a work day. Raise the bubble tubes in each water supply 25 mm (1 in.) per hour until excess water appears on the upper surfaces of the samples or until 8 hours have passed. Then lower the bubble tubes to the 152-mm (6-in.) level for another 16 hours. After the 24-hour saturation period is complete, lower the bubble tubes to the 1.0-mm (0.5-in.) level and open the clamps on the drain lines outside the cabinet. The next step is to insert the thermocouples.

6.4.5 Inserting the thermocouples

Each sample is instrumented with eight thermocouples (T/Cs). The T/Cs are numbered 1 through 8 and each set is numbered 1,2,3 or 4. The T/Cs are placed in the sides of the samples with the number 1 T/C located at the top. Place the bottom T/C first and work up. Dip the tip of the T/C into silicone rubber and push the sharp end through the ring and rubber membrane into the sample, about 6.5 mm (0.25 in.) as shown in Figure 13. Puncturing the membrane with the end of a paper clip will make this procedure easier in some cases. After placing all the T/Cs, dab a little silicone rubber on the place where the T/Cs penetrate the Plexiglas rings. Plug the T/Cs into the junction box, observing the proper order as marked. You are now ready to complete the test assembly.




Figure 13. Location of thermocouples in the sample.

6.4.6 Completing the test assembly

Remove the lead weights and plastic disks from the top of the samples. Place the cold plate assemblies on top of the samples and fold up the rubber membranes to overlap the cold plates and clamp and seal with rubber bands (Fig. 4). Connect the lines from the refrigerated bath to the

upper cold plate assembly. Place the lead surcharge weights on the cold plates and center. Place the DCDT and dial gauge assemblies on the aluminum rods and lower and center the dial gauges so that they read 0.00 in. Plug the DCDTs into the appropriate terminals on the junction box and proceed to check their operation.

6.4.7 Checking operation of DCDTs

Turn on the computer, thermal printer, cassette drive, data logger and power supply and press the following keys:

- a. USER on.
- b. LOG.

The DCDT readings will be printed out on the thermal paper. Proper readings will range between -30 and -20 mm. Check connections and make necessary adjustments if the readings are unacceptable. If DCDTs are working properly, proceed to instructions for starting the freezing test.

7. CONDUCTING THE TEST

The computer programs used for running the freeze test allow the periodic scanning of the test data, the automatic control of the boundary temperatures, reduction and analysis of the data, printing of the results on the thermal paper and recording the results on a tape cassette. The last data scan will be made at 120.5 hours, at which time the critical heave rate data will be summarized and the logging and control system will automatically shut down. The program flow chart is shown in Figure 14. An example of the data printout is given in Appendix D. Begin the freeze test by loading the running programs as follows.

7.1 Loading the running programs

- a. Place the cassette marked New Freeze in the cassette drive.
- b. Turn on the cassette drive to standby mode.
- c. Turn on the thermal printer to standby and manual modes. Make sure that the paper supply is full.
- d. Turn on the data logger and the computer.
- e. Clear the main memory by pressing:
 - (1) a ALAMAZ a.
 - (2) XEQ a PCLPS a.
- f. Load the data logging and temperature control programs into the computer by pressing the following key sequence:

(1) α FRST α .

(2) XEQ α READP α .

The programs will be automatically loaded. Approximately 3.5 minutes is required. Wait for the display to show a numerical configuration before proceeding.

g. Proceed to instructions on starting the test.




Figure 14. Flow chart for data acquisition and temperature control program.

7.2 Starting the test

a. Place the data cassette tape into the cassette drive.

b. Start running the programs by pressing:

(1) USER on.

(2) LN.

c. The HP41CX calculator will then prompt you for test information as follows:

(1) SERIES NAME?

(2) SAMPLE 1 NAME?

(3) SAMPLE 2 NAME?

(4) SAMPLE 3 NAME?

(5) SAMPLE 4 NAME?

} Respond to each question with no more than seven alpha-numeric characters followed by pressing the R/S key.

(6) CONTROL T?

Enter Y if computer controls the temperatures, N if not.

(7) FREEZE TEMPERATURE?

Enter the freezing point of the pore water in degrees Celsius by pressing the R/S key.

(8) DATE?

Respond with the appropriate date in MM.DDYY format, followed by the R/S key; defaults to the current date if only R/S key is pressed.

(9) TIME?

Respond with the desired start time in HH.MMSSSS format followed by the R/S key; defaults to the current time plus one minute if only R/S key is pressed.

d. Data scanning will begin automatically upon pressing the R/S command. Data scans are made every 1 hour unless another period is selected later. An example is shown in Figure 15.

e. Data scans can be made at other times by pressing:

(1) USER on.

(2) $\Sigma + .$

.....
 TIME 17.43
 DATE: 4.271904
 E TIME: 32.0006 HOURS

BERG1

TP-1

DEPTH TEMP. MM	DEG C
0.00	-2.54
12.70	-1.93
30.10	-0.82
63.50	0.09
90.90	0.74
114.30	1.53
139.70	2.34
152.40	2.72

FROST PEN. = 60.9 MM
 FROST HEAVE = 0.2 MM
 PEN. RATE = 20.0 MM/DAY
 HEAVE RATE = 0.0 MM/DAY
 HEAVE RATIO = 0.04
 SEC. POT. = 93.2 MM²/
 DEG C-SEC

TP-2

DEPTH TEMP. MM	DEG C
0.00	-2.67
12.70	-1.04
30.10	-0.40
63.50	0.55
90.90	0.00
114.30	1.79
139.70	2.41
152.40	2.83

FROST PEN. = 49.9 MM
 FROST HEAVE = 0.2 MM
 PEN. RATE = 24.5 MM/DAY
 HEAVE RATE = 0.6 MM/DAY
 HEAVE RATIO = 0.02
 SEC. POT. = 99.2 MM²/
 DEG C-SEC

MP-1

DEPTH TEMP. MM	DEG C
0.00	-2.04
12.70	-1.55
30.10	-0.49
63.50	0.19
90.90	0.94
114.30	1.61
139.70	2.20
152.40	2.86

FROST PEN. = 56.4 MM
 FROST HEAVE = 0.7 MM
 PEN. RATE = 47.4 MM/DAY
 HEAVE RATE = 1.2 MM/DAY
 HEAVE RATIO = 0.03
 SEC. POT. = 194.5 MM²/
 DEG C-SEC

MP-2

DEPTH TEMP. MM	DEG C
0.00	-2.24
12.70	-1.56
30.10	-0.69
63.50	0.00
90.90	0.71
114.30	1.42
139.70	2.17
152.40	2.34

FROST PEN. = 60.8 MM
 FROST HEAVE = 0.7 MM
 PEN. RATE = 23.8 MM/DAY
 HEAVE RATE = 1.9 MM/DAY
 HEAVE RATIO = 0.00
 SEC. POT. = 264.1 MM²/
 DEG C-SEC

COLD BATH = -2.92 DEG C
 WARM BATH = 3.11 DEG C
 GRADIENT = 1.13 DEG C
 ICE BATH = 0.00 DEG C

TAPE POINTER = 3.240.00

Figure 15. Example of test results for a single scan.

This intermediate data scan option will not respond if a programmed scan is scheduled within the next 8 minutes. The message, WAIT FOR SCHEDULED SCAN, will be seen on the display and the thermal printer type. DO NOT INTERRUPT A SCAN IN PROGRESS — WAIT UNTIL THE FULL SEQUENCE OF DATA LOGGING, PRINTING ON THE THERMAL PAPER, AND RECORDING ON THE TAPE CASSETTE IS COMPLETE.

f. Proceed to nucleation instructions.

7.3 Nucleation

a. The first 24 hours is a tempering period. After 24 hours has elapsed since starting the test, the first freezing cycle will begin. At approximately 24.5 hours, make a data scan by putting USER on and pressing \sqrt{X} . If the top thermocouple readings are 1.0°C lower than the freezing point of the soil water, enable nucleation by opening the freezing cabinet and delivering two sharp blows to the tops of each cold plate through the aluminum rod. Scan the data once more. The top thermocouple temperature will rise if nucleation occurred. Other evidence of nucleation may be positive frost heave rates on the printouts. Repeat this process for additional 0.5°C drops in the top thermocouple temperatures until nucleation is achieved.

b. Repeat the nucleation procedure for the second freeze-thaw cycle, which begins at 72 hours.

c. Proceed to observing the test instructions.

7.4 Observing the test

a. Ensure that boundary temperatures are correct. If the temperatures are set manually, then adjust the dials on the baths. Clockwise turns increase the temperature; counterclockwise turns decrease the temperature. If the temperatures are being controlled automatically, then no adjustments can be made (except to MAKE SURE THAT THE BATH TEMPERATURE DIAL IS SET TO 15°C OR GREATER).

The bath temperatures can be scanned by pressing:

- (1) USER.
- (2) \sqrt{X} .

b. Make sure that the thermocouple reference has not drifted. If the ice bath temperature reported on the data printout is greater than 0.06°C , then the ice bath may need to be remade. If the ice bath is good, then adjust the reference junction to within $\pm 0.03^{\circ}\text{C}$ of 0.0°C .

The ice bath temperature can be scanned by pressing:

- (1) USER.
- (2) \sqrt{X} .

c. Ensure that the ambient temperature is maintained between 0° and 1°C . The ambient temperature can be observed by pressing:

- (1) USER.
- (2) \sqrt{X} .

d. Check that the thermal printer has an adequate supply of paper. Approximately three rolls of paper are needed for each test. Particular attention should be given to ensuring that there is a fresh roll of paper at the beginning of a freeze cycle, especially if the test is to run unattended for more than 24 hours. After replacing tape, press XEQ α PRA α to make sure that the printer is working properly. If the printer runs out of tape, the entire scanning and temperature control procedure will be interrupted.

e. Ensure that the cassette tape has sufficient space available. The TAPE POINTER location printed out at the end of each data listing indicates how many data spaces have been used. The scheduled data scans require 9000 data spaces on the tape; 16,000 data spaces are available on the tape, which allows space for 7000 intermediate pieces of data (72 per scan) or approximately 100 extra scans.

f. The sample bases need to be purged of air, particularly after a thaw. To do this, disconnect and lower the drainage lines located outside the freezing cabinet and allow them to drain until air bubbles cease to appear. If a large amount of air is present, a slight suction applied by mouth to the drain hose should start the flow. Refill the water supply if necessary, after purging the sample bases of air.

g. Make sure that the water supply tubes are adequately filled and are operating correctly.

h. Make and record dial gauge readings, particularly at the ends of freezing or thawing legs, and compare what you see with the frost heaves recorded on the thermal paper. These readings should agree to within ± 0.2 mm, as both the dial gauge and DCDT transducer are mechanically linked.

7.5 Completing the test

The last data scan will occur at 120.5 hours. The computer is programmed to print END OF TEST and to summarize the heave rate data for both freeze cycles on the thermal printer paper (Fig. 16). The entire data logging system will then shut down automatically. Disassemble the apparatus as follows.

a. Make and record dial gauge readings. Check to see if they are in agreement with frost heaves.

b. After the data logging system has shut down, turn off the refrigerated circulating baths and the freezing cabinet.

END OF TEST

TEST SERIES BERGI

CRITICAL FROST HEAVE
RATES, MM/DAY

SAMPLE ID	FREEZE NO	8 HOURS		16 HOURS	
TP-1	1	0.8	4.5		
	2	7.6	8.2		
TP-2	1	0.6	4.6		
	2	8.4	9.2		
MP-1	1	1.2	8.5		
	2	2.7	8.8		
MP-2	1	1.9	8.2		
	2	2.6	8.7		

Figure 16. Example of summary printout at the end of a test.

c. Remove dial gauge and DCDT assemblies.

d. Remove surcharge weights.

e. Remove cold plate assemblies as follows: clamp off the two plastic tubes leading to the refrigerated circulating bath from cold plates 1 and 4. Then disconnect the two tubes from the cold plates, being careful not to spill the ethylene-glycol solution. Use a short piece of plastic tubing to temporarily connect the two cold plate assemblies as a unit.

f. Remove enough of the loose insulation to allow access to the thermocouple assemblies and water lines.

g. Remove the thermocouples from the sides of the samples by pulling each gently away from the Plexiglas rings.

h. Clamp the water lines and disconnect the plastic tubes from the base of each sample.

i. Remove each sample assembly, complete with each base.

j. Proceed to instructions for CBR test.

7.6 Conducting the CBR test after thawing

Conduct the CBR test immediately after 120.5 hours have elapsed.

a. Remove the samples from the bases and carefully place them in plastic bags and seal tightly. One at a time, remove the plastic bags and carefully place the samples on an aluminum pie plate of known tare weight. Weigh the sample and the pie plate. Slide a 150-mm (6-in.) diameter hose clamp over each ring and tighten. The hose clamps restrain expansion of the Plexiglas rings during the CBR test.

- b. Remove the plastic film from on top of the sample.
- c. Conduct the CBR test using standard procedures, but limiting the penetration to 7.6-mm (0.3-in.) depth. Record the results.
- d. Take a small water content sample from the area where the CBR piston penetrated the wall. Determine wet and dry weights and water content.
- e. Remove the hose clamps, rings and rubber membrane from the sample and cut it into six equal slices. Determine the water content of each slice. Also determine weight of the water left in the pie pan.

7.7 Presenting the data

- a. Enter the series and sample names on the data sheet provided (Appendix D). Record also the compaction water content, dry density, porosity, and degree of saturation and freezing point depression.
- b. The final printout of the data will summarize the frost heave rates during each freeze-thaw cycle. Check to see if these data agree with what was recorded on the thermal paper during the test. Record these data on the data sheet.
- c. Plot the frost heave and frost penetration versus time on the data sheet. Check to ensure that the heave rate calculations are accurate.
- d. Record the before and after freezing and thawing CBR values on the data sheet along with the corresponding water contents.
- e. Plot the before and after freezing and thawing water content profiles on the data sheet.

7.8 Determining the frost susceptibility

Use the two heave rates and the CBR values to determine the frost susceptibility. As this test is only currently under development, exact criteria have not been established. Further correlations with field observations must be made. However, tentative frost susceptibility criteria are given in Table 3.

Compare the 8-hour frost heave rates observed during the first and second freeze-thaw cycles with each other. If there is a significant increase (or decrease) during the second freeze, as there is in the example shown in Figure 17, then the heave rate value selected will depend on the location of the construction site. If the site is in a very temperate region where many freeze-thaw cycles occur and the water table is near the zone of freezing and thawing, then the 8-hour heave rate during the second

Table 3. Tentative frost susceptibility criteria for the new freeze-thaw test.

Frost susceptibility classification	8-hour heave rate (mm/day)	Thaw CBR (%)
Negligible	<1	>20
Very low	1-2	20-15
Low	2-4	15-20
Medium	4-8	10-5
High	8-16	5-2
Very high	>16	<2




Figure 17. Example of the effect of freezing and thawing on frost heave rate.

freeze should be selected. If the site is in a more severe winter climate where the frost penetration is more continuous during the winter, then the 8-hour heave rate during the first freeze should be selected.

The heave rate criteria allow the determination of the frost heave susceptibility of a material that can be related to pavement roughness during the freezing period. The thaw CBR value allows the determination of the thaw weakening susceptibility of the material. Compare the thaw CBR value with the tentative criteria in Table 3 to determine the thaw weakening susceptibility. The actual thaw weakening criteria must be determined by the engineer and the design practice employed. At the moment, it does not appear useful to use the percent reduction in CBR as the thaw weakening criterion.

8. DISCUSSION OF TEST RESULTS

An example of the test results is shown in Figure 17. It can be seen for this case that the frost heave rate is much greater during the second freeze than during the first. This reveals the importance of conducting at least two freeze-thaw cycles. This does not always happen, but can be




Figure 18. Correlation of laboratory and field frost heave rates.




Figure 19. Comparison of laboratory CBR test results after freezing and thawing with field pavement deflection.

generally expected for soils containing a significant amount of clay-sized particles. As previously discussed, the decision on which of the two heave rates should be used for assessing the frost susceptibility depends primarily on site conditions. Figure 18 shows that, for the series of tests conducted to date with the new freezing test, the heave rates from first freeze correlate with the field observations. In all cases, the water table remained below the depth of cyclic frost penetration.

In many cases, the frost heave susceptibility will not be the controlling factor for determining the frost susceptibility of the material. Figure 19 shows a comparison of the CBR after thawing with the field pavement deflection during thawing. It can be seen that for the Sibley till material, the thaw weakening was very high, whereas the heave rate during

the first freeze (Fig. 18) was very low. Table 3 shows that the resulting frost susceptibility classification of this soil would be based on its thaw weakening susceptibility.

Because this test is conducted under rather severe conditions, it can be expected to err on the conservative side. To make it more discriminating, it is possible to conduct the test with conditions more nearly like field conditions. Adjusting the water table to a lower level would require the inclusion of a porous stone with a 1-atmosphere air entry value at the base. Increasing the surcharge would require additional weights on the surface of the test samples. These procedures can be accomplished with additional effort and hardware. However, it is recommended that less severe conditions of freezing be simulated by conducting the tests on unsaturated samples under the closed condition of no water supply. If tests are conducted with both the open and closed system freezing, then the limits of frost susceptibility of a soil can be determined.

9. CONCLUSIONS

The freezing test described here can be used to determine the frost susceptibility of soils and granular base materials. The determination of the frost susceptibility can be based on one of three factors: 1) the frost heave rate during the first freeze, 2) the heave rate during the second freeze, or 3) the CBR after the second thaw. The factor selected as controlling the frost susceptibility must be related to the site conditions.

The test can be conducted under very severe conditions of open water supply freezing or under closed system freezing. The actual site conditions should be considered before determining which test method is appropriate.

This test reduces the time for determining the frost susceptibility of a soil to half that needed for the standard test.

The test procedures should be followed closely to ensure repeatability and reliability. The automated test equipment removes much of the variability normally resulting because of human error. However, close attention to the details of sample preparation and test setup is still necessary.

Since any new test, such as the freezing test described in this report, requires a considerable amount of effort to establish its effi-

ciency, it should be understood that this test needs further study. Ideally, it should be applied in the field under a wide range of conditions. To this end CRREL is willing to cooperate with transportation departments, universities, consulting firms and individuals interested in determining the frost susceptibility of granular soils used in road construction. This can be done by contracting with CRREL to conduct tests, by obtaining a set of shop drawings (which CRREL will provide) and by constructing the necessary equipment or by contracting with CRREL to provide the test equipment.

10. LITERATURE CITED

- Chamberlain, E.J. and D.L. Carbee (1981) The CRREL frost heave test. Frost I Jord, 22:55-63.
- Chamberlain, E.J. (1981) Frost susceptibility of soil - Review of index tests. USA Cold Regions Research and Engineering Laboratory, Hanover N.H., CRREL Monograph 81-2
- Chamberlain, E.J. (1984) An automated soils freezing test. In Proceedings of the Second National Conference on Microcomputers in Civil Engineering, Oct. 30-31, Nov. 1, Orlando, Florida (W.E. Carroll, Ed.). Orlando: University of Central Florida, p. 1-5.
- Chamberlain, E.J. (1986) Evaluation of selected frost susceptibility test methods. USA Cold Regions Research and Engineering Laboratory, Hanover, N.H., CRREL Report 86-14, and U.S. Department of Transportation, Federal Aviation Administration, Report DOT/FAA/PM 85-17.
- Haley, J.F. and C.W. Kaplar (1952) Cold room studies of frost action in soils. Highway Research Board, Special Report 2, p. 246-267.
- Hewlett-Packard Co. (1982) Operating, programming and configuration manual, model 3421A data acquisition/control unit. Loveland, Colorado.
- Kaplar, C.W. (1974) Freezing test for evaluating relative frost susceptibility of various soils. USA Cold Regions Research and Engineering Laboratory, Hanover, N.H., CRREL Technical Report 250.

APPENDIX A: ASSEMBLING THE APPARATUS

The test apparatus includes a freezer cabinet, four sample assemblies, four water supplies with drainage lines, four DCDTs, four sets of thermocouples, two refrigerated circulating baths, one data acquisition and control system, one temperature control interface, and one power supply.

The following instructions are for connecting the various parts and for making some initial control settings:

- a. Set the freezer chest on the floor, leaving it on the wooden pallet. Plug it into a 20-A, 115-V circuit. Turn it on by setting the green switch on the lower right front of the chest to I and the yellow switch to S. You should hear the muffled hum of the compressor. In a few minutes you should notice the interior beginning to cool. Allow the chest to cool down for 24 hours. Proceed to the next step while the freezer is cooling.
- b. Place a table of approximately 1.5 x 1 m (5 x 3.5 ft) dimensions to the left of the freezer. Place on the table the two circulating baths as shown in Figure 3. To the right of the circulating baths, place the data logging and control system and, to the rear of the data logger, put the power supply.
- c. Check the operation of the refrigerated baths. Connect the inlet and outlet ports with a short piece of tubing. Plug the baths into two separate 20-A, 115-V circuits. Turn on both baths with the cooling system and heat switches. Turn the temperature selector switches to the DIAL positions and the local/remote switches to the local positions. Set the large dial to approximately -20°C and wait 30 minutes for the baths to cool. Use the thermometers positioned in the baths to ensure the proper response.
- d. Connect the insulated circulation lines leading from the freezer chest to the refrigerated circulating baths. Make sure that bath 1 is connected to the top cold plates and bath 2 to the bottom cold plate, and that the inlet and outlet connections are made as marked.
- e. Connect the temperature interface control box to the two cold baths with the two large cable connectors, as marked. Using the cable with

a small connector on one end and three insulated wires on the other, connect the control box to terminal block 2 on the HP3421A data acquisition unit. Connect the black wire to channel 20 low, the white wire to channel 21 low, and the red wire to channel 20 high. Connect channels 20 high and 21 high together with a jumper wire.

f. Connect cables 1, 2 and 3 to terminal blocks 0, 1, and 2 as shown in Appendix B.

g. Connect the power supply leads between the number 2 high and low terminals on terminal block 2 to the power supply, making sure the marked polarity is observed.

h. Set up the data acquisition and control system as shown in Figure 4, making sure that the labeled sequence of connections is made.

APPENDIX B: DATA ACQUISITION AND CONTROL SYSTEM

B1. Circuit connections for thermocouples and DCDTs




Figure B1. Schematic for wiring of thermocouple junction box.




Figure B2. Schematic of single-ended thermocouple connections to multiplexer cards 0 and 1 in the HP3421A data logger (after Hewlett-Packard 1982).





Figure B3. Connections to multiplexer card 2 in the HP3421 data logger (after Hewlett-Packard 1982).

B2. Data logger settings



HP3421 A multiplexer card configuration.

Card	JM06/16* JM05/15	JM09/19* JM08/18	JM1* JM2	J6†	J7†	J8**
0	install	cut	cut	1	1	out
1	install	cut	cut	0	0	out
2	cut	install	install	1	1	out

* Configures channels 0 and 1 as either actuators or multiplexers; locations shown above.

† Tells mainframe how channels 0 and 1 are configured; locations not shown. See manual for further details.

**Bypasses attenuator on channel 2.

Figure B4. HP3421A data logger multiplexer card configurations (after Hewlett-Packard 1982).

B3. Set-up of refrigerated circulating baths

Each bath requires 15-A service. It is recommended that the baths be plugged into different circuits.

- a. Rear panel switches:
 - Remote/local - Local
 - Programmer/accessory - Off
- b. Front panel switches:
 - PWR - On
 - Cooling system - On
 - Setpoint select - Dial
- c. Turn dial to desired temperature.
- d. Ensure that bath is filled with proper fluid to correct level.
- e. Plug in option 1 control box.

- f. Connect cables to bath 1 and bath 2 as marked on option 1 box.
- g. Connect cable to HP3421A data acquisition system channel 20 and channel 21; red wire to both channel high's, black wire to channel 20 low, white wire to channel 21 low.
- h. Energize option 1 control box.
- i. Allow system to operate at least 4 hours before attempting any temperature adjustments.
- j. Adjust dial and fine tune for desired dial temperature. Allow 5 minutes, after HEAT light begins to flash, between adjustments to ensure system stability.
- k. Once dial and fine tune are set, the fine tune knob must not be adjusted again. Note position (setting) of fine tune.
- l. Select T_2 and adjust only the T_2 pot for desired temperature. Do not use fine tune. Wait 5 minutes as in step 10. A clockwise adjustment increases bath temperature.
- m. Repeat step 12 for T_1 and T_0 .
- n. Once all setpoints have been adjusted, set local/remote switch on rear panel to remote.
- o. Connect HP41CX to HP3421A. Ensure that the remote/local switch is in remote. Verify temperature settings by selecting temperature setpoints with calculator and observing temperature at which they stabilize (see Table B1).

Table B1. Relay settings for temperature control.

Channel 20	Channel 21	Selected setting
0*	0	T_0
0	1	T_2
1	0	Dial
1	1	T_1

*0 = open relay; 1 = closed relay.

APPENDIX C: PROGRAM LISTINGS

C1. Freeze test program

These programs are all stored on the tape cassette marked NEW FREEZE.

NAME	TYPE	REGS
ALMRST	PR	5
ILOG	PR	13
ALMA	PR	27
TAPE	PR	5
PRDATA	PR	101
FRST	PR,A	19
REGRESS	PR	14
REDUCE	PR	47
FRDATA	PR	17
FRPEN	PR	27
DATA	PR	33
SCAN	PR	54
TLOG	PR	18
TBATHS	PR	23
SCANLMP	PR	34
SCANZ	PR	104
ALAMAZ	PR	38
FR	PR,A	11
TCONTRL	PR	76
FREEZE6	WA	336
FREEZE2	WA	336
TEND	PR	65

C2. Program to load setup programs

This program automatically loads programs used in the initial setup of the freeze test. To load:

- a. Place NEW FREEZE program tape in cassette drive.
- b. Turn on all devices in loop.
- c. Press α FR α .
- d. XEQ α READP α .

Time required to load FR is 1 minute and 10 seconds.

4:57PM 03.04	
01*LBL "FR"	
02 CF 11	• Disables automatic execution flag.
03 1	
04 STO 01	
05 "PR"	
06 ASTO 02	
07 "DA"	
08 ASTO 03	
09*LBL 04	
10 RCL 01	
11 ENDIRX	
12 RCL 02	
13 X=Y?	
14 GTO 01	
15 RDM	
16 RCL 03	
17 X=Y?	
18 GTO 01	
19 GTO 03	
20*LBL 01	
21 PURFL	
22 GTO 04	
23*LBL 03	
24 "TSAVE2"	
25 36	Creates "TSAVE2" file in EM.
26 CRFLD	
27 "TSAVE3"	
28 45	Creates "TSAVE3" file in EM.
29 CRFLD	
30 "FREEZE2"	
31 READA	
32 .END.	Loads main memory files, set flags and key assignments and fills registers with proper constants.

C3. Setup programs

CAT 1

LBL'ALAMAZ
END 260 BYTES
LBL'SCANLMP
END 237 BYTES
LBL'TBATHS
END 161 BYTES
LBL'TAPE
END 35 BYTES
LBL'SCANZ
.END. 728 BYTES

- ALAMAZ - calibrates thermocouple zeros.
- SCANLMP - scans and prints DCDTs.
- TBATHS - scans and prints bath temperatures.
- TAPE - initializes data tape.
- SCANZ - subroutine for ALAMAZ.

CAT 4

TSRVE2 D036
TSRVE3 D045
515.0000 ***

USER KEYS:

12 "TAPE"
13 "TBATHS"
14 "SCANLMP"
15 "ALAMAZ"

- TAPE is assigned to "1/X" key.
- SCANZ - subroutine for ALAMAZ.
- SCANLMP is assigned to "LOG" key.
- ALAMAZ is assigned to "LN" key.

STATUS:

SIZE= 100
Σ= 11
DEG
FIX 4

C4. Initial Register storage for the setup programs

R00= 0.000000
R01= 0.000000
R02= 0.000000
R03= 0.000000
R04= 0.000000
R05= 0.000000
R06= 0.000000
R07= 0.000000
R08= 0.000000
R09= 0.000000
R10= 0.000000
R11= 0.000000
R12= 0.000000
R13= 0.000000
R14= 0.000000
R15= 0.000000
R16= 0.000000
R17= 0.000000
R18= 0.000000
R19= 0.000000
R20= 0.000000
R21= 0.000000
R22= 0.000000
R23= 0.000000
R24= 0.000000
R25= 2.000000
R26= 0.000000
R27= 0.000000
R28= 0.000000
R29= 0.000000
R30= 0.000000
R31= 0.000000
R32= 0.000000
R33= 0.000000
R34= 0.000000
R35= 0.000000
R36= 0.000000
R37= 0.000000
R38= 0.000000
R39= 0.000000
R40= 0.000000
R41= 0.000000
R42= 0.000000
R43= 0.000000
R44= 0.000000
R45= 0.000000
R46= 0.000000
R47= 0.000000
R48= 0.000000
R49= 0.000000

R50= 0.000000
 R51= 0.000000
 R52= 0.000000
 R53= 0.000000
 R54= 0.000000
 R55= 0.000000
 R56= 0.000000
 R57= 0.000000
 R58= 0.000000
 R59= 0.000000
 R60= 0.000000
 R61= 0.000000
 R62= 0.000000
 R63= 0.000000
 R64= 0.000000
 R65= 0.000000
 R66= 0.000000
 R67= 0.000000
 R68= 0.000000
 R69= 0.000000
 R70= 0.000000
 R71= 0.000000
 R72= 0.000000
 R73= 0.000000
 R74= 12.700000
 R75= 38.100000
 R76= 63.500000
 R77= 88.900000
 R78= 114.300000
 R79= 139.700000
 R80= 152.400000
 R81= 0.000038
 R82= 0.000000
 R83= 0.000000
 R84= 0.000000
 R85= 0.000000
 R86= 0.000000
 R87= 0.000000
 R88= 9.498900
 R89= 0.000000
 R90= 0.000000
 R91= 0.000000
 R92= 0.000000
 R93= 0.000000
 R94= 0.000000
 R95= 0.000000
 R96= 0.000000
 R97= 0.000000
 R98= 0.000000
 R99= 0.000000

{
 }
 }

Thermocouple depths in millimetres.

Thermocouple calibrations in V/°C.

DCDT calibration in mm/V for 6 V-dc input.

C5. Initial flag status for setup programs

FLAGS:

F 00 CLEAR
F 01 CLEAR
F 02 CLEAR
F 03 CLEAR
F 04 CLEAR
F 05 CLEAR
F 06 CLEAR
F 07 CLEAR
F 08 CLEAR
F 09 CLEAR
F 10 CLEAR
F 11 CLEAR
F 12 CLEAR
F 13 CLEAR
F 14 CLEAR
F 15 CLEAR
F 16 CLEAR
F 17 CLEAR
F 18 CLEAR
F 19 CLEAR
F 20 CLEAR
F 21 SET
F 22 SET
F 23 SET
F 24 CLEAR
F 25 CLEAR
F 26 SET
F 27 CLEAR
F 28 SET
F 29 SET
F 30 CLEAR
F 31 SET
F 32 CLEAR
F 33 CLEAR
F 34 CLEAR
F 35 CLEAR
F 36 CLEAR
F 37 SET
F 38 CLEAR
F 39 CLEAR
F 40 SET
F 41 CLEAR
F 42 CLEAR
F 43 CLEAR
F 44 CLEAR
F 45 CLEAR
F 46 CLEAR
F 47 CLEAR
F 48 CLEAR
F 49 CLEAR
F 50 CLEAR
F 51 CLEAR
F 52 CLEAR
F 53 CLEAR
F 54 CLEAR
F 55 SET

C6. Program to determine the thermocouple zero calibrations during initial setup

1 24PM 03.04	
01*LBL "ALAMAZ"	
02 OF 27	
03 "HP3421A"	Turns off USER.
04 FINDID	
05 SELECT	Makes data logger primary device.
06 0	
07 STO 07	Initializes scan number counter.
08 "TSAVE3"	
09 000.	
10 SEEKPTA	Stores depth data in EM file "TSAVE3."
11 073.000	
12 SAVERX	
13 00.04301	
14 STO 95	
15*LBL 04	
16 0.0	
17 STO IND 95	Places zeros in R08-R43 and in extended memory file "TSAVE2."
18 ISG 95	
19 GTO 04	
20 "TSAVE2"	
21 000.	
22 SEEKPTA	
23 000.043	
24 SAVERX	
25 "SERIES NAME?"	
26 AON	
27 PROMPT	
28 ASTO 00	
29 "SAMP1 NAME?"	
30 PROMPT	
31 ASTO 01	Prompts for series and sample names (limit to 7 alpha-numeric characters).
32 "SAMP2 NAME?"	
33 PROMPT	
34 ASTO 02	
35 "SAMP3 NAME?"	
36 PROMPT	
37 ASTO 03	
38 "SAMP4 NAME?"	
39 PROMPT	
40 ASTO 04	
41 AOFF	
42 "NO. OF SCANS?"	Prompts for number of scans.
43 PROMPT	
44 STO 90	
45 "SCAN INT?"	Prompts for scan interval; defaults to 30 minutes if there is no input.
46 PROMPT	
47 FC?C 22	
48 00.3000	
49*LBL 00	

50 "START DATE"
51 PROMPT
52 FC?C 22
53 DATE
54 STO 05
55 "START TIME?"
56 PROMPT
57 FC?C 22
58 TIME
59 .0010
60 HMS+
61 STO 06
62 "↑↑SCANZ"
63 XYZALM
64 END

}
Prompts for start date; defaults to current date.

}
Prompts for start time; defaults to current time plus 10 seconds.

}
Sets alarm to trigger SCANZ program.

C7. Subroutine for ALAMAZ

1 19PM 03.04

01*LBL "SCANZ"

02 1

03 ST+ 07

04 SF 04

05 00

06*LBL 04

07 "CLS"

08 ARCL X

09 OUTA

10 "LS02-19:F1T3"

11 OUTA

12 FS? 04

13 GTO 01

14 08.02501

15 GTO 02

16*LBL 01

17 26.04301

18*LBL 02

19 STO 95

20*LBL 05

21 IND

22 STO IND 95

23 ISG 95

24 GTO 05

25 FS?C 04

26 GTO 01

27 GTO 03

28*LBL 01

29 "OPN00"

30 OUTA

31 01

32 GTO 04

33*LBL 03

34 "OPN01"

35 OUTA

36 "OPN19"

37 OUTA

38*LBL 09

39 "-----"

40 PRA

41 FIX 2

42 "TIME= "

43 ACA

44 TIME

45 ACX

46 PRBUF

47 CLA

48 "DATE= "

49 ACA

50 FIX 6

51 DATE

52 ACX

53 PRBUF

54 CLA

55 FIX 2

56 "-----"

57 PRA

Increments counter for scan number.

Sets flag to enable low/high side single-ended readings.

Identifies low side relay 00.

Closes low side relay if preceded by 00, high side if preceded by 01.

Reads dc-voltage on channels 02-19 and stores data in 3421A buffer.

Sets up storage of low side readings in R26-R43 and high side readings in R08-R25

Sends dc-voltage data from 3421A buffer to R08-R43 in HPO41CX.

Flag 04 set for low side readings just made; if set, clears flag 04 and changes channel ID to 01 to enable high side readings, and returns to LBL04 to read relays 2-19 again.

Opens relays 01 and 19.

Prints time and date heading.

58 CLA	
59 PRA	
60 SF 12	
61 FC? 05	
62 GTO 01	
63 "AVG TC ZEROS"	Prints "T/C ZERO" reading if flag 12 is clear;
64 GTO 00	prints "AVG T/C ZEROS" if flag 12 is set.
65*LBL 01	
66 "T/C ZEROS"	
67*LBL 00	
68 PRA	
69 CLA	
70 PRA	Prints series identification.
71 ARCL 00	
72 PRA	
73 "TSAVE3"	
74 000.	Gets depth data from EM.
75 SEEKPTA	
76 073.000	
77 GETRX	
78 00.03901	Sets counter for T/Cs.
79 STO 95	
80 01.00401	Sets counter for sample IDs.
81 STO 98	
82*LBL 08	
83 CLA	
84 PRA	
85 SF 12	Prints sample identification.
86 ARCL IND 98	
87 PRA	
88 CF 12	
89 CLA	
90 PRA	
91 73.08001	Sets counter for depths.
92 STO 99	
93 CLA	
94 " DEPTH "	
95 ACA	
96 " TEMP"	
97 ACA	Prints headings for depth and temperature.
98 ADV	
99 "MM "	
100 ACA	
101 " DEG C"	
102 ACA	
103 ADV	
104 CLA	
105 PRA	
106*LBL 10	
107 RCL IND 99	
108 ACX	
109 2	
110 SKPCHR	Calculates and prints depth and temperature.
111 RCL IND 95	
112 RCL 81	
113 /	
114 STO IND 95	
115 ACX	
116 ADV	

117 ISG 95
 118 GTO 01
 119*LBL 01
 120 ISG 99
 121 GTO 10
 122 CLA
 123 PRA
 124 ISG 98
 125 GTO 00
 126 40.04301
 127 STO 95
 128*LBL 12
 129 RCL IND 95
 130 RCL 81
 131 /
 132 STO IND 95
 133 ISG 95
 134 GTO 12
 135 FIX 2
 136 CLA
 137 PRA
 138 "COLD BATH= "
 139 ACA
 140 RCL 40
 141 ACX
 142 " DEG C"
 143 ACA
 144 PRBUF
 145 CLA
 146 "WARM BATH= "
 147 ACA
 148 RCL 41
 149 ACX
 150 " DEG C"
 151 ACA
 152 PRBUF
 153 CLA
 154 "AMBIENT= "
 155 ACA
 156 RCL 42
 157 ACX
 158 " DEG C"
 159 ACA
 160 PRBUF
 161 CLA
 162 "ICE BATH= "
 163 ACA
 164 RCL 43
 165 ACX
 166 " DEG C"
 167 ACA
 168 PRBUF
 169 CLA
 170 PRA
 171 "END OF READING"
 172 PRA

Sets counter for cold-bath, warm-bath and ice-bath
 temperatures, and ambient temperature.

Calculates and prints cold-bath, warm-bath and ice-
 bath temperatures, and ambient temperature.

173 FS?C 05	}	If flag 05 is set then six sets of readings have been made.
174 GTO 11		
175 "TSAVE2"		
176 000.	}	Gets [T/C data from EM.
177 SEEKPTA		
178 044.079		
179 GETRX	}	Sets counter for [T/C data.
180 44.07901		
181 STO 96		
182 00.04301	}	Sets counter for T/C data just read.
183 STO 95		
184 LBL 13		
185 RCL IND 95	}	
186 RCL IND 96		
187 +		
188 STO IND 96	}	Adds current T/C data to [T/C data.
189 ISG 95		
190 GTO 01		
191 LBL 01	}	
192 ISG 96		
193 GTO 13		
194 "TSAVE2"	}	
195 000.		
196 SEEKPTA		Stores [T/C data in EM.
197 044.079	}	
198 SAVERX		
199 RCL 90		
200 RCL 07	}	If number of scans equals number of scans desired; proceeds to determining average T/C zeros.
201 X<Y?		
202 GTO 07		
203 044.07901	}	Sets counter for [T/C data.
204 STO 96		
205 00.04301		
206 STO 95	}	Sets counter for T/C data just read.
207 LBL 06		
208 RCL IND 96		
209 RCL 07	}	
210 /		
211 RCL 81		
212 *	}	Calculates average T/C zeros, clears the alarms, sets flag 05 to enable printing "AVG. T/C ZERO" heading, and returns to section for printing headings, and depth and temperature data.
213 STO IND 95		
214 ISG 96		
215 GTO 00	}	
216 LBL 00		
217 ISG 95		
218 GTO 06	}	
219 CLRALMS		
220 SF 05		
221 GTO 09	}	
222 LBL 11		
223 "TSAVE2"		
224 000.	}	Saves "AVG T/C ZERO" data in EM.
225 SEEKPTA		
226 00.043		
227 SAVERX		

228+LBL 07
229 +TSAVE3+
230 000.
231 SEEKPTA
232 073.000
233 GETRX
234 PWRDN
235 OFF
236 END

}

Returns depth data from EM to R73-R80.

C8. Program to make readings of the displacement transducers during setup

1:26PM 03.04

01*LBL "SCANLMP"

02 CF 27

03 "HP3421A"

04 FINDID

05 SELECT

06 "LS22-26:F1T3"

07 OUTA

08 44.04801

09 STO 95

10*LBL 06

11 IND

12 STO IND 95

13 ISG 95

14 GTO 06

15 "OPN26"

16 OUTA

17 45.04801

18 STO 95

19*LBL 14

20 RCL IND 95

21 RCL 88

22 *

23 RCL 44

24 *

25 6

26 /

27 STO IND 95

28 ISG 95

29 GTO 14

30 FIX 1

31 CLA

32 PRA

33 "DCDT1= "

34 ACA

35 RCL 45

36 ACX

37 " MM."

38 ACA

39 PRBUF

40 CLA

41 "DCDT2= "

42 ACA

43 RCL 46

44 ACX

45 " MM."

46 ACA

47 PRBUF

48 CLA

49 "DCDT3= "

50 ACA

51 RCL 47

52 ACX

53 " MM."

54 ACA

55 PRBUF

• Clears USER.

Makes data logger primary device.

Reads dc-voltage data on channels 22-26 and stores values in R44-R48 in HP41CX.

Opens channel 26.

Sets counter for voltage data from DCDTs.

Converts dc-voltage data to displacement in millimetres.

Prints the DCDT readings in millimetres.

56 CLA
57 "DCBT4= "
58 ACA
59 RCL 48
60 ACX
61 " MM. "
62 ACA
63 PRBUF
64 CLA
65 FIX 4
66 "PWR IN= "
67 ACA
68 RCL 44
69 ACX
70 " DCV "
71 ACA
72 PRBUF
73 CLA
74 PRA
75 "END OF READING"
76 END

Continuation of displacement DCDT printout.

C9. Program to scan the bath temperatures during setup

1:29PM 03.04

01•LBL "TBATHS"

02 PWRUP

03 CF 27

04 "TSAVE2"

05 032.

06 SEEKPTA

07 098.099

08 GETRX

09 "CLS00"

10 OUTA

11 "LS16-17:F1T3"

12 OUTA

13 00.00901

14 STO 95

15•LBL 01

16 IND

17 STO IND 95

18 ISG 95

19 GTO 01

20 CLA

21 "COLD BATH= "

22 ACA

23 RCL 08

24 RCL 81

25 /

26 RCL 98

27 -

28 ACX

29 " DEG C"

30 PRBUF

31 CLA

32 "WARM BATH= "

33 ACA

34 RCL 09

35 RCL 81

36 /

37 RCL 99

38 -

39 ACX

40 " DEG C"

41 PRBUF

42 CLA

43 PRA

44 "OPN17"

45 OUTA

46 PWRDN

47 OFF

48 END

• Powers up devices.

• Clears USER.

} Gets T/C zero data for bath temperatures from EM and stores in R98 and R99.

} Reads channels 16 and 17 and stores data in R08 and R09.

} Calculates and prints cold-bath temperature in °C.

} Calculates and prints warm-bath temperature in °C.

} Opens last channel opened on data logger.

• Powers down devices.

• Turns off HP41CX.

C10. Program to initialize the data tape cassette during setup

Tape must be first initialized to contain 1 file by:
XEQ "NEWM 0 0 1," which is assigned to 1/X.

1:33PM 03.04

01•LBL "TAPE"

02 SF 20

03 CLA

04 ARCL 00

05 16000

06 CREATE

07 0

08 STO 89

09 SEEKR

10 RTN

11 .END.

• Tape enable on.

} Places series name in alpha register.

} Sets up 16,000 registers on tape.

} Sets pointer to zero and stores 0 in R89.

C11. Program to load running programs

This program automatically loads system running programs for the freezing test. To load:

- a. Place NEWFREEZE program tape in cassette drive.
- b. Turn on all devices in loop.
- c. Press aFRSTa and XEQaREADPa.

The time required to load is 3 minutes, 20 seconds. Automatic execution flag (F11) is set automatically when program FRST is read from cassette.

4:59PM 03.04	
01+LBL "FRST"	
02 CF 11	• Disables automatic execution flag.
03 "TSAVE4"	
04 16	Creates "TSAVE4" file in EM.
05 CRFLD	
06 "TSAVE5"	
07 2	Creates "TSAVE5" file in EM.
08 CRFLD	
09 "TCONTRL"	
10 READSUB	
11 SAVEP	
12 "DATA"	
13 READP	
14 SAVEP	
15 "FRPEN"	
16 READP	
17 SAVEP	
18 "FRDATA"	
19 READP	
20 SAVEP	
21 "REDUCE"	
22 READP	
23 SAVEP	
24 "REGRESS"	
25 READP	
26 SAVEP	
27 "PRDATA"	
28 READP	
29 SAVEP	
30 "TEND"	
31 READP	
32 SAVEP	
33 "FREEZE6"	
34 READP	
35 .END.	Loads main memory (MM) files and key assignments, sets flags, and places constants in storage registers.

C12. Running programs

FRST

CAT 1

LBL'ILOG
END 31 BYTES
LBL'TLOG
END 126 BYTES
LBL'ALMA
END 189 BYTES
LBL'SCAN
END 370 BYTES
LBL'TCONTRL
LBL'AL1
LBL'AL2
LBL'AL3
LBL'AL4
LBL'AL5
LBL'AL6
LBL'AL7
LBL'AL8
LBL'AL9
LBL'AL10
LBL'ALMRST
LBL'ALMREL
.END. 544 BYTES

Main memory files.

CAT 4

TSAVE2 D036
TSAVE3 D045
TSAVE4 D016
TSAVE5 D002
TCONTRL P077
DATA P034
FRPEN P028
FRDATA P018
REDUCE P048
REGRESS P015
PRDATA P102
TEND P066

Extended memory files.

89.0 ***

USER KEYS:

13 "ILOG" \sqrt{x}
15 "TLOG" LN

Programs assigned to keys.

STATUS

SIZE= 100
Σ= 11
DEG
FIX 1

Initial calculator status.

C13. Running program register storage

R00= 0.0000	R50= 0.0000
R01= 0.0000	R51= 0.0000
R02= 0.0000	R52= 0.0000
R03= 0.0000	R53= 0.0000
R04= 0.0000	R54= 0.0000
R05= 0.0000	R55= 0.0000
R06= 0.0000	R56= 0.0000
R07= 0.0000	R57= 0.0000
R08= 0.0000	R58= 0.0000
R09= 0.0000	R59= 0.0000
R10= 0.0000	R60= 0.0000
R11= 0.0000	R61= 0.0000
R12= 0.0000	R62= 0.0000
R13= 0.0000	R63= 0.0000
R14= 0.0000	R64= 0.0000
R15= 0.0000	R65= 0.0000
R16= 0.0000	R66= 0.0000
R17= 0.0000	R67= 0.0000
R18= 0.0000	R68= 0.0000
R19= 0.0000	R69= 0.0000
R20= 0.0000	R70= 0.0000
R21= 0.0000	R71= 0.0000
R22= 0.0000	R72= 0.0000
R23= 0.0000	R73= 0.0000
R24= 0.0000	R74= 12.7000
R25= 0.0000	R75= 38.1000
R26= 0.0000	R76= 63.5000
R27= 0.0000	R77= 88.9000
R28= 0.0000	R78= 114.3000
R29= 0.0000	R79= 139.7000
R30= 0.0000	R80= 152.4000
R31= 0.0000	R81= 3.8000-05
R32= 0.0000	R82= 0.0000
R33= 0.0000	R83= 0.0000
R34= 0.0000	R84= 0.0000
R35= 0.0000	R85= 0.0000
R36= 0.0000	R86= 0.0000
R37= 0.0000	R87= 0.0000
R38= 0.0000	R88= 9.4989
R39= 0.0000	R89= 0.0000
R40= 0.0000	R90= 0.0000
R41= 0.0000	R91= 0.0000
R42= 0.0000	R92= 0.0000
R43= 0.0000	R93= 0.0000
R44= 0.0000	R94= 0.0000
R45= 0.0000	R95= 0.0000
R46= 0.0000	R96= 0.0000
R47= 0.0000	R97= 0.0000
R48= 0.0000	R98= 0.0000
R49= 0.0000	R99= 0.0000

Thermocouple depths in millimetres.

T/C calibration in V-dc/°C.

DCTC calibration in millimetres.

C14. Flag settings

FLAGS:

F 00 CLEAR
F 01 CLEAR
F 02 CLEAR
F 03 CLEAR
F 04 CLEAR
F 05 CLEAR
F 06 CLEAR
F 07 CLEAR
F 08 CLEAR
F 09 CLEAR
F 10 CLEAR
F 11 CLEAR
F 12 CLEAR
F 13 CLEAR
F 14 CLEAR
F 15 CLEAR
F 16 CLEAR
F 17 CLEAR
F 18 CLEAR
F 19 CLEAR
F 20 CLEAR
F 21 SET
F 22 CLEAR
F 23 CLEAR
F 24 CLEAR
F 25 CLEAR
F 26 SET
F 27 CLEAR
F 28 SET
F 29 SET
F 30 CLEAR
F 31 SET
F 32 CLEAR
F 33 CLEAR
F 34 CLEAR
F 35 CLEAR
F 36 CLEAR
F 37 CLEAR
F 38 CLEAR
F 39 SET
F 40 SET
F 41 CLEAR
F 42 CLEAR
F 43 CLEAR
F 44 CLEAR
F 45 CLEAR
F 46 CLEAR
F 47 CLEAR
F 48 CLEAR
F 49 CLEAR
F 50 CLEAR
F 51 CLEAR
F 52 CLEAR
F 53 CLEAR
F 54 CLEAR
F 55 SET

All user delegated flags are clear.

Automatic execution flag is clear.

All external device control flags are clear.

System operation control flags (see HP-41CX owner's manual for details).

C15. ILOG

This program allows data readings to be made between regular scan intervals. A SCAN will not be allowed if a scheduled reading is to occur within 8 minutes. The program is assigned to \sqrt{X} key; press USER, then \sqrt{X} key to execute ILOG.

3:42PM 04.05		
01•LBL "ILOG"	.	Clears USER key.
02 CF 27	}	Recalls first alarm parameters; if no alarm is set, goes to SCAN.
03 SF 25		
04 I		
05 RCLALM		
06 FC? 25		
07 GTO 02	}	If time left before next alarm is less than 8 minutes (0.1333 hour) then will not scan.
08 CF 25		
09 TIME		
10 HMS-		
11 HR		
12 .1333	}	Makes data logger primary device.
13 X>Y?		
14 GTO 01		
15•LBL 02		
16 "HP3421A"		
17 FINDID	.	Executes SCAN program.
18 SELECT	}	Prints message if SCAN is not allowed.
19 XEQ "SCAN"		
20•LBL 01		
21 "WAIT FOR SCHED"		
22 "RULED SCAN"		
23 PRA		
24 RVIEW		
25 END		

C16. TLOG

This program ensures that zeros are placed in certain storage registers and data files. Data logger is made primary device in HPIL loop. It executes alarm program to start readings.

4:29PM 04/18	
01*LBL "TLOG"	
02 SF 09	• Sets flag to identify first scan.
03 CF 27	• Turns off USER key.
04 000.072	
05 CLRGX	
06 002.007	
07 CLRGX	
08 009.099	
09 CLRGX	
10 "TSAVE3"	
11 000.	
12 SEEKPTA	
13 000.044	
14 SAVERX	
15 "TSAVE4"	
16 000.	
17 SEEKPTA	
18 000.015	
19 SAVERX	
20 "TSAVE5"	
21 000.	
22 SEEKPTA	
23 000.001	
24 SAVERX	
25 "HP3421A"	
26 FINDID	
27 SELECT	
28 XEQ "ALMA"	• Executes "ALMA" program.
29 END	

Puts zeros in R00-R72, R82-R87 and R90-R99.
 Puts zeros in file "TSAVE3" in the EM of HP41CX.
 Puts zeros in "TSAVE4" in EM.
 Puts zeros in "TSAVE5" in EM.
 Finds and makes the HP3421A data logger the primary device.

C17. ALMA

This program provides prompts for test information and executes setting of alarms.

2:35PM 04/02	
01•LBL "ALMA"	
02 "SERIES NAME?"	
03 AON	
04 PROMPT	Prompts for series name and stores in R00.
05 ASTO 00	
06 "SAMP1 NAME?"	
07 PROMPT	
08 ASTO 01	
09 "SAMP2 NAME?"	
10 PROMPT	
11 ASTO 02	
12 "SAMP3 NAME?"	Prompts for sample names and stores in R01-R04.
13 PROMPT	
14 ASTO 03	
15 "SAMP4 NAME?"	
16 PROMPT	
17 ASTO 04	
18 AOFF	
19 "FREEZE TEMP?"	
20 PROMPT	Prompts for freezing point depression and stores in R94.
21 STO 94	
22 CF 22	
23 "START DATE?"	
24 PROMPT	Prompts for start date; defaults to current date if only R/S is pushed.
25 FC?C 22	
26 DATE	
27 "START TIME?"	
28 PROMPT	
29 FC?C 22	
30 TIME	
31 .01	
32 HMS+	Prompts for start time; defaults to current time plus 1 minute if only R/S is keyed.
33 ENTER↑	
34 24	
35 /	Stores start date in R82.
36 ENTER↑	
37 RDN	Stores start time in R83.
38 INT	
39 DATE+	
40 STO 82	
41 RCL Z	
42 FPC	
43 24	
44 *	
45 STO 83	
46 XEQ "TCONTRL"	Executes TCONTRL alarm setting program
47 2	
48 RCL 32	
49 RCL 83	
50 "↑↑SCAN"	Sets SCAN alarm to 2 hour intervals.
51 XYZALM	
52 END	

C18. SCAN

```

1:50PM 30.04
01*LBL "SCAN"
02 CF 27
03 SF 04
04 DATE
05 STO 05
06 TIME
07 STO 06
08 00
09*LBL 12
10 "CLS"
11 ARCL X
12 OUTA
13 "LS02-19:F1T3"
14 OUTA
15 FS? 04
16 GTO 00
17 00.02501
18 GTO 01
19*LBL 00
20 26.04301
21*LBL 01
22 STO 95
23*LBL 04
24 IND
25 STO IND 95
26 ISG 95
27 GTO 04
28 FS?C 04
29 GTO 03
30 GTO 02
31*LBL 03
32 "OPN00"
33 OUTA
34 01
35 GTO 12
36*LBL 02
37 "OPN01"
38 OUTA
39 "LS22-26:F1T3"
40 OUTA
41 44.04801
42 STO 95
43*LBL 08
44 IND
45 STO IND 95
46 ISG 95
47 GTO 08
48 "OPN26"
49 OUTA

```

• Clears USER.

• Sets flag for low side readings.

Places date and time of readings in R05 and R06.

Closes low side relay if preceded by 00 and high side relay if 01.

Reads dc-voltage stepwise on channels 2-19 and stores results in 3421A buffer.

Sets up storage of low side readings in R26-R43 and high side readings in R08-R25.

Sends dc-voltage data from buffer to R08-R43 in HP41CX.

Flag 04 is set if low side readings just made: if set, enables channel ID change to 01 to enable high side readings and returns to LBL 12 to read relays 2-19 again. If flag 04 is cleared, proceeds to read channels 22-26, opens relays 00 and 01 before reading 22-26.

Reads dc-voltage stepwise on channels 22-26, stores in buffer.

Sends dc-voltage data from buffer to R44-R48.

Opens last channel relay.

50 "DATA"	}	Gets "DATA" program from EM and reduces dc-voltage data to °C and mm.
51 GETP		
52 XEQ "DATA"		
53 "FRPEN"		
54 GETP	}	Gets "FRPEN" program from EM and calculates the frost penetrations.
55 XEQ "FRPEN"		
56 "REDUCE"		
57 GETP		
58 "FRDATA"	}	Gets "REDUCE," "FRDATA" and "REGRESS" programs from EM and determines: 1) frost heave rate, 2) frost penetration, 3) frost penetration rate, 4) heave ratio, and 5) segregation potential.
59 GETSUB		
60 "REGRESS"		
61 GETSUB		
62 XEQ "REDUCE"	}	
63 "REDUCE"		
64 PCLPS		
65 "PRDATA"		
66 GETP	}	Gets "PRDATA" program from EM and prints out test results.
67 XEQ "PRDATA"		
68 01.072		
69 STO 99		
70 CLA	}	
71 ARCL 00		
72 RCL 89		
73 SEEKR		
74 RCL 99	}	Writes data on tape cassette.
75 WRTX		
76 72		
77 ST+ 89		
78 "TSAVE4"	}	
79 000.		
80 SEEKPTA		
81 049.064		
82 GETRX	}	Returns data from EM to main memory (MM).
83 "TCONTRL"		
84 GETP		
85 049.053004		
86 REGMOVE	}	
87 045.049004		
88 REGMOVE		
89 061.065004		
90 REGMOVE	}	Shifts past two sets of frost heave and frost penetration readings to new storage for rate calculations.
91 057.061004		
92 REGMOVE		
93 CF 10		
94 RCL 07	}	
95 120.5		
96 X>Y?		
97 GTO 01		
98 "TEND"	}	Enables termination of test if the elapsed time is greater than 120.5 hours.
99 GETP		
100 GTO "TEND"		
101 LBL 01		
102 PWRDN	•	Turns off devices.
103 OFF		
104 END		Turns off HP41CX.

C19. Program to control bath temperatures during the freeze-thaw test

```

10 51AM 05.05
01 LBL "TCONTRL"
02 SF 08
03 0
04 "↑↑AL1"
05 GTO "ALMREL"
06 LBL "AL1"
07 "OPN20"
08 XEQ "OUTA"
09 "CLS21"
10 XEQ "OUTA"
11 16
12 "↑↑AL2"
13 GTO "ALMREL"
14 LBL "AL2"
15 "OPN21"
16 XEQ "OUTA"
17 24
18 "↑↑AL3"
19 GTO "ALMREL"
20 LBL "AL3"
21 "CLS20"
22 XEQ "OUTA"
23 CF 08
24 .3
25 STO 99
26 XEQ "ALMRST"
27 32
28 "↑↑AL4"
29 GTO "ALMREL"
30 LBL "AL4"
31 "CLS21"
32 XEQ "OUTA"
33 48
34 "↑↑AL5"
35 GTO "ALMREL"
36 LBL "AL5"
37 "OPN20"
38 XEQ "OUTA"
39 SF 08
40 2.0
41 STO 99
42 XEQ "ALMRST"
43 64
44 "↑↑AL6"
45 GTO "ALMREL"
46 LBL "AL6"
47 "OPN21"
48 XEQ "OUTA"
49 72
50 "↑↑AL7"
51 GTO "ALMREL"

```

Prevents printing of dh/dt , etc., in PRDATA.

Sets alarm at $t_0 + 6$ minutes for setting bath temperatures at $T_1 = 12^\circ\text{C}$ and $T_2 = 3^\circ\text{C}$, and triggers alarm.

Sets bath temperatures at $t_0 + 6$ minutes + 16 hours to $T_1 = 3^\circ\text{C}$ and $T_2 = 3^\circ\text{C}$.

Sets bath temperatures at $t_0 + 6$ minutes + 24 hours to $T_1 = -3^\circ\text{C}$ and $T_2 = 3^\circ\text{C}$.

Enables printing of dh/dt , etc., in PRDATA, resets scan interval to 30 minutes.

Resets scan interval to 30 minutes.

Sets bath temperatures at $t_0 + 6$ minutes + 32 hours to $T_1 = -12^\circ\text{C}$ and $T_2 = 0.5^\circ\text{C}$.

Sets bath temperatures at $t_0 + 6$ minutes + 48 hours to $T_1 = 12^\circ\text{C}$ and $T_2 = 3^\circ\text{C}$.

Disables printing of dh/dt , etc.

Resets scan interval to 2 hours.

Sets bath temperatures at $t_0 + 6$ minutes + 64 hours to $T_1 = 3^\circ\text{C}$ and $T_2 = 3^\circ\text{C}$.

```

52*LBL "AL7"
53 "CLS20"
54 XEQ "OUTA"
55 CF 08
56 .3
57 STO 99
58 XEQ "ALMRST"
59 30
60 "++AL8"
61 GTO "ALMREL"
62*LBL "AL8"
63 "CLS21"
64 XEQ "OUTA"
65 96
66 "++AL9"
67 GTO "ALMREL"
68*LBL "AL9"
69 "OPN20"
70 XEQ "OUTA"
71 SF 08
72 2.0
73 STO 99
74 XEQ "ALMRST"
75 112
76 "++AL10"
77 GTO "ALMREL"
78*LBL "AL10"
79 "OPN21"
80 XEQ "OUTA"
81 GTO 09
82*LBL "ALMRST"
83 1
84 XEQ "RCLALM"
85 X<> Z
86 RDN
87 RCL 99
88 X<> Z
89 "++SCAN"
90 XEQ "CLALMA"
91 XYZALM
92 RTN

```

Sets bath temperatures at $t_0 + 6$ minutes + 72 hours to $T_1 = -3^\circ\text{C}$ and $T_2 = 3^\circ\text{C}$.

Enables printing of dh/dt , etc.

Resets scan interval to 30 minutes.

Sets bath temperatures at $t_0 + 6$ minutes + 80 hours to $T_1 = -12^\circ\text{C}$ and $T_2 = -0.5^\circ\text{C}$.

Sets bath temperatures at $t_0 + 6$ minutes + 96 hours to $T_1 = 12^\circ\text{C}$ and $T_2 = 3^\circ\text{C}$.

Disables printing of dh/dt , etc.

Rests scan interval to 2 hours.

Sets bath temperatures at $t_0 + 6$ minutes + 112 hours to $T_1 = 3^\circ\text{C}$ and $T_2 = 3^\circ\text{C}$.

Goes to end of program.

Subroutine to reset scan interval.

```

93*LBL "ALMREL"
94 RCL 83
95 HMS+
96 .06
97 HMS+
98 ENTER†
99 ENTER†
100 24
101 /
102 INT
103 RCL 82
104 X<>Y
105 DATE+
106 LASTX
107 24
108 *
109 ST- Z
110 CLX
111 STO T
112 RDN
113 X<>Y
114 XYZALM
115*LBL 09
116 PWRDN
117 OFF
118 .END.

```

Subroutine to set alarms for temperature changes.

- Turns off devices.
- Turns off HP41CX.

C20. Program to reduce the thermocouple data and the DCDT data during the freeze-thaw test

```

11 37AM 04/03
01*LBL "DATA"
02 RCL 02
03 RCL 05
04 DDAYS
05 24
06 *
07 RCL 06
08 RCL 03
09 HMS-
10 HMS+
11 HR
12 STO 07
13 "TSAVE3"
14 000.
15 SEEKPTA
16 045.000
17 SAYERX
18 "TSAVE2"
19 000.
20 SEEKPTA
21 045.000
22 GETRX
23 45.00001
24 STO 92
25 00.04301
26 STO 95
27*LBL 05
28 RCL IND 95
29 RCL 01
30 /
31 RCL IND 92
32 -
33 STO IND 95
34 ISG 95
35 GTO 00
36*LBL 00
37 ISG 92
38 GTO 05
39*LBL 00
40 "TSAVE3"
41 000.
42 SEEKPTA
43 045.000
44 GETRX
45 FS?C 09
46 GTO 02
47 GTO 03

```

Calculates elapsed time in hours:

```

R80  start date
R05  current date
R06  current time
R83  start time
R07  elapsed time.

```

Saves data in R45-R80 in EM.

Gets T/C zero data from EM; stores in R45-R80.

Sets T/C zero counter.

Sets T/C temperature counter.

Converts dc-voltage data for T/Cs to 0°C and corrects for zero shift:

$$^{\circ}\text{C} = \text{V-dc} / 3.8 \times 10^{-5} \text{ V-dc}/^{\circ}\text{C}$$

$$\text{R81} \leftarrow 3.8 \times 10^{-5}.$$

Returns data from EM to R45-R80 in MM.

Determines if first data pass (FS09) is made and enables determination of initial DCDT data.


```

48*LBL 02
49 45.04801
50 STO 96
51 84.08701
52 STO 99
53*LBL 04
54 RCL IND 96
55 RCL 44
56 *
57 6
58 /
59 STO IND 99
60 ISG 96
61 GTO 00
62*LBL 00
63 ISG 99
64 GTO 04
65*LBL 03
66 45.04801
67 STO 96
68 84.08701
69 STO 99
70*LBL 06
71 RCL IND 96
72 RCL 44
73 *
74 6
75 /
76 RCL IND 99
77 -
78 RCL 88
79 *
80 STO IND 96
81 ISG 96
82 GTO 00
83*LBL 00
84 ISG 99
85 GTO 06
86 RTN
87 END

```

Determines initial DCDT settings, corrects for input voltage drift from 6.0 V and stores results in R84-R87.

Sets frost heave counter.

Sets DCDT_{zero} counter.

Calculates the frost heave for each sample and stores results in R45-R48.

• Returns to SCAN.

C21. Program to determine the depth of frost penetration during the freeze-thaw test

3:26PM 04/18
01*LBL "FRPEN"
02 08.03900
03 STO 99
04 69.07201
05 STO 93
06 45.04801
07 STO 96
08 57.06001
09 STO 97
10*LBL 12
11 RCL 99
12 .00007
13 -
14 STO 95
15 73.07901
16 STO 90
17*LBL 04
18 RCL 95
19 1
20 +
21 STO 92
22 RCL IND 95
23 RCL 94
24 -
25 SIGN
26 RCL IND 92
27 RCL 94
28 -
29 SIGN
30 X*Y?
31 GTO 00
32 ISG 95
33 GTO 03
34*LBL 03
35 ISG 90
36 GTO 04
37 RCL IND 95
38 RCL 94
39 -
40 SIGN
41 X>0?
42 GTO 01
43 RCL IND 96
44 152.4
45 +
46 STO IND 97
47 GTO 02
48*LBL 01
49 0
50 STO IND 97
51 GTO 02

Sets T/C temperature counter by 08.

Sets gradT counter.

Sets frost heave counter.

Sets frost penetration counter.

Sets T/C temperature counter by 01.

Sets depth counter.

Looks for depth interval where freezing occurs;
exits to determine actual frost depth when
interval is found.

Checks to see if sample is completely frozen or
thawed.

If completely frozen, sets frost penetration to
152.4 mm.

If completely thawed, sets frost penetration to 0 mm.

```

52+LBL 00
53 RCL 90
54 1
55 +
56 STO 91
57 RCL IND 91
58 RCL IND 90
59 -
60 RCL IND 92
61 RCL IND 95
62 -
63 /
64 1/X
65 STO IND 93
66 RCL 94
67 RCL IND 95
68 -
69 X<>Y
70 /
71 RCL IND 90
72 +
73 STO IND 97
74+LBL 02
75 ISG 99
76 GTO 02
77+LBL 02
78 ISG 97
79 GTO 02
80+LBL 02
81 ISG 93
82 GTO 02
83+LBL 02
84 ISG 96
85 GTO 12
86 RTN
87 .END.

```

Uses linear interpolation to determine frost depth.

Increments T/C counter.

Increments frost penetration counter.

Increments gradT counter.

Increments frost heave counter.

• Returns to SCAN.

C22. Program to determine the frost heave and frost penetration rates, frost heave ratio, and segregation potential

3:29PM 04/18		
01*LBL "REDUCE"		
02 CLA	•	Clears alpha register.
03 RCL 07	}	Stores [time in R90.
04 STO 90		
05 "TSAVE5"	}	
06 000.		
07 SEEKPTA		Gets previous two times from "TSAVE5" in EM and
08 091.092		stores in R91 and R92.
09 GETRX	}	
10 "TSAVE3"		
11 000.		Stores data in R00-R44 in EM ("TSAVE3").
12 SEEKPTA		
13 000.044	}	
14 SAVERX		
15 45.04801		
16 STO 96		
17 49.05201	}	h_1
18 STO 20		h_2
19 53.05601		h_3
20 STO 21		H_1
21 57.06001		H_2
22 STO 97		H_3
23 61.06401		
24 STO 22		
25 65.06801		
26 STO 23		
27 69.07201	}	SP_0 and gradT
28 STO 93		
29 00.00301		
30 STO 12		
31 04.00701		
32 STO 13		
33 08.01101		
34 STO 14		
35*LBL 04		
36 XEQ "FRDATA"		•
37 ISG 96	}	
38 GTO 00		
39*LBL 00		
40 ISG 20		
41 GTO 00		
42*LBL 00		
43 ISG 21		
44 GTO 00		
45*LBL 00		
46 ISG 97		
47 GTO 00		
48*LBL 00		
49 ISG 22		
50 GTO 00		
51*LBL 00		
52 ISG 23		
53 GTO 00		
54*LBL 00		

Sets counters.

Increments counters.

55 ISG 93
 56 GTO 00
 57 LBL 00
 58 ISG 12
 59 GTO 00
 60 LBL 00
 61 ISG 13
 62 GTO 00
 63 LBL 00
 64 ISG 14
 65 GTO 04
 66 LBL 00
 67 "TSAVE4"
 68 000.
 69 SEEKPTA
 70 049.064
 71 SAVERX
 72 000.049004
 73 REGMOVE
 74 004.053004
 75 REGMOVE
 76 000.061004
 77 REGMOVE
 78 "TSAVE3"
 79 000.
 80 SEEKPTA
 81 000.044
 82 GETRX
 83 RCL 91
 84 STO 92
 85 RCL 90
 86 STO 91
 87 "TSAVE5"
 88 000.
 89 SEEKPTA
 90 091.092
 91 SAVERX
 92 RTN
 93 .END.

Increments counters.

Saves data in R49-R64 in EM (TSAVE4).

Moves $\frac{dh}{dH}$, $\frac{dh}{dt}$, $\frac{dH}{dt}$ to new storage in MM.

Returns T/C temperature data to MM from EM.

Places first two time readings into second two storage registers R91 and R92, and stores in EM (TSAVE5).

Returns to SCAN.

C23. Subroutine to determine heave and penetration rates, frost heave ratio, and segregation potential

3:32PM 04/18		
01*LBL "FRDATA"		
02 RCL IND 96	}	Places current heave value in R30.
03 STO 30		
04 RCL IND 20	}	Places previous two heave values in R31 and R32.
05 STO 31		
06 RCL IND 21	}	Calculates heave rate in mm/hr.
07 STO 32		
08 XEQ "REGRESS"	}	Converts to mm/day.
09 RCL 25		
10 24	}	Converts to mm/day.
11 *		
12 STO 26	}	Places current penetration value in R30.
13 STO IND 13		
14 RCL IND 97	}	Places previous two heave values in R31 and R32.
15 STO 30		
16 RCL IND 22	}	Calculates frost penetration rate in mm/hr.
17 STO 31		
18 RCL IND 23	}	Converts to mm/day.
19 STO 32		
20 XEQ "REGRESS"	}	Converts to mm/day.
21 RCL 25		
22 24	}	Calculates dh/dH.
23 *		
24 STO 25	}	Calculates segregation potential.
25 STO IND 14		
26 RCL 26	}	Returns to "REDUCE."
27 RCL 25		
28 X=0?	}	
29 GTO 00		
30 RCL 26	}	
31 RCL 25		
32 /	}	
33 GTO 01		
34*LBL 00	}	
35 0		
36*LBL 01	}	
37 STO IND 12		
38 RCL IND 93	}	
39 X=0?		
40 GTO 00	}	
41 RCL 26		
42 4.2694	}	
43 *		
44 RCL IND 93	}	
45 /		
46 GTO 01	}	
47*LBL 00		
48 0	}	
49*LBL 01		
50 STO IND 93	}	
51 RTN		
52 .END.		

C24. Program to determine heave rates and penetration rates by regression analysis

```

3:33PM 04/18
01+LBL "REGRESS"
02 RCL 30
03 RCL 90
04 *
05 RCL 31
06 RCL 91
07 *
08 +
09 RCL 32
10 RCL 92
11 *
12 +
13 STO 40
14 RCL 30
15 RCL 31
16 +
17 RCL 32
18 +
19 STO 41
20 RCL 90
21 RCL 91
22 +
23 RCL 92
24 +
25 STO 42
26 RCL 90
27 X↑2
28 RCL 91
29 X↑2
30 +
31 RCL 92
32 X↑2
33 +
34 STO 43
35 RCL 40
36 RCL 41
37 RCL 42
38 *
39 3
40 /
41 -
42 RCL 43
43 RCL 42
44 X↑2
45 3
46 /
47 -
48 /
49 STO 25
50 RTN
51 .END.

```

$\sum xy$

$\sum y$ (heave or penetration)

$\sum x$ (time)

$\sum x^2$

$$\frac{dh}{dt} \text{ or } \frac{dH}{dt} = \frac{\sum xy - \frac{\sum x \sum y}{n}}{\sum x^2 - \frac{(\sum x)^2}{n}}$$

• Returns to FRDATA.

C25. Program to print test results and to store results on a tape cassette

10:17AM 04/19

01 LBL "PRDATA"

02 ".....";

03 PRA

04 FIX 2

05 "TIME: "

06 ACA

07 RCL 06

08 ACX

09 PRBUF

10 CLA

11 "DATE: "

12 ACA

13 FIX 6

14 RCL 05

15 ACX

16 PRBUF

17 CLA

18 FIX 4

19 "Σ TIME: "

20 ACA

21 RCL 07

22 ACX

23 " HOURS"

24 ACA

25 PRBUF

26 CLA

27 "....."

28 PRA

29 CLA

30 PRA

31 SF 12

32 ARCL 00

33 PRA

34 08.03901

35 STO 95

36 45.04001

37 STO 96

38 01.00401

39 STO 98

40 49.05201

41 STO 90

42 53.05601

43 STO 91

44 57.06001

45 STO 97

46 61.06401

47 STO 92

48 69.07201

49 STO 93

Prints main heading.

Prints series ID.

T/C data

Frost heave

Sample ID

dh/dH

dh/dt

H

dH/dt

SP₀

Sets counters.

50+LBL 04
 51 CLA
 52 PRA
 53 SF 12
 54 ARCL IND 98
 55 PRA
 56 CF 12
 57 CLA
 58 PRA
 59 FIX 2
 60 73.00001
 61 STO 99
 62 CLA
 63 " DEPTH"
 64 ACA
 65 " TEMP."
 66 ACA
 67 ADV
 68 "MM"
 69 ACA
 70 " DEG C"
 71 ACA
 72 ADV
 73 CLA
 74 PRA
 75+LBL 03
 76 RCL IND 99
 77 ACX
 78 2
 79 SKPCHR
 80 RCL IND 95
 81 ACX
 82 ADV
 83 ISG 95
 84 GTO 09
 85+LBL 09
 86 ISG 99
 87 GTO 03
 88 CLA
 89 PRA
 90 FIX 1
 91 "FROST PEN. ="
 92 ACA
 93 RCL IND 97
 94 ACX
 95 " MM"
 96 ACA
 97 PRBUF
 98 CLA
 99 "FROST HEAVE ="
 100 ACA
 101 RCL IND 96
 102 ACX
 103 " MM"
 104 ACA
 105 PRBUF
 106 FS? 08
 107 GTO 06
 108 CLA

Prints sample ID.

Sets depth counter.

Prints heading for depth and temperature.

Prints depth and temperature.

Prints frost penetration.

Prints frost heave.

If flag 08 is set, disables printing of $\frac{dh}{dt}$, $\frac{dH}{dt}$,
 $\frac{dH}{dh}$ and SP_o .

109 "PEN. RATE="	}	Prints frost penetration rate.
110 ACA		
111 RCL IND 92		
112 ACX		
113 "MM/DAY"		
114 ACA	}	Prints frost heave rate.
115 PRBUF		
116 CLA		
117 "HEAVE RATE="		
118 ACA		
119 RCL IND 91	}	Prints frost heave ratio.
120 ACX		
121 "MM/DAY"		
122 ACA		
123 PRBUF		
124 CLA	}	Prints segregation potential.
125 FIX 2		
126 "HEAVE RATIO="		
127 ACA		
128 RCL IND 90		
129 ACX	}	Prints segregation potential.
130 PRBUF		
131 CLA		
132 FIX 1		
133 "SEG. POT.="		
134 ACA	}	Prints segregation potential.
135 RCL IND 93		
136 ACX		
137 "MM+2/"		
138 ACA		
139 PRBUF	}	Prints segregation potential.
140 CLA		
141 "DEG C-SEC"		
142 ACA		
143 FIX 3		
144 ADV	}	Increments counters.
145 CLA		
146 PRA		
147*LBL 06		
148 1		
149 ST+ 96	}	Increments counters.
150 ST+ 98		
151 ST+ 90		
152 ST+ 91		
153 ST+ 97		
154 ST+ 92	}	Increments counters.
155 ISG 93		
156 GTO 04		

157 FIX 2	}	Prints bath 1 temperature.
158 CLA		
159 PRA		
160 "COLD BATH= "		
161 ACA		
162 RCL 40	}	Prints bath 2 temperature.
163 ACX		
164 "DEG C"		
165 ACA		
166 PRBUF		
167 CLA	}	Prints ambient temperature.
168 "WARM BATH= "		
169 ACA		
170 RCL 41		
171 ACX		
172 "DEG C"	}	Prints ice bath temperature.
173 ACA		
174 PRBUF		
175 CLA		
176 "AMBIENT= "		
177 ACA	}	Prints tape location.
178 RCL 42		
179 ACX		
180 "DEG C"		
181 ACA		
182 PRBUF	}	Prints END OF READING.
183 CLA		
184 "ICE BATH= "		
185 ACA		
186 RCL 43		
187 ACX	}	Returns to SCAN.
188 "DEG C"		
189 ACA		
190 PRBUF		
191 CLA		
192 PRA	}	Returns to SCAN.
193 "TAPE POINTER= "		
194 ACA		
195 RCL 89		
196 ACX		
197 PRBUF	}	Returns to SCAN.
198 CLA		
199 PRA		
200 "END OF READING"		
201 PRA		
202 CLA	}	Returns to SCAN.
203 "-----"		
204 ACA		
205 "-----"		
206 ACA		
207 PRBUF	}	Returns to SCAN.
208 CLA		
209 PRA		
210 RTN		
211 .END.		

C26. Program to summarize test results and shut down the freeze-thaw test

12:56PM 30.04	
01*LBL "TEND"	
02 CLRALMS	• Clears all alarms.
03 CLA	}
04 PRA	
05 SF 12	
06 "END OF TEST"	
07 PRA	Prints end of test.
08 CF 12	}
09 CLA	
10 PRA	
11 " TEST SERIES: "	
12 ARCL 00	
13 ACA	
14 PRBUF	
15 CLA	
16 PRA	
17 " CRITICAL "	
18 "FROST HEAVE"	
19 PRA	
20 CLA	
21 " RATES "	
22 "t, MM/DAY"	
23 PRA	
24 CLA	
25 PRA	
26 "SAMPLE FREEZE"	
27 "t 0 16"	
28 PRA	
29 CLA	
30 " ID NO "	
31 "t-HOURS HOURS"	
32 PRA	
33 CLA	
34 PRA	
35 0	
36 1800	
37 STO 88	
38 32	
39 STO 89	
40 051.054	
41 STO 87	
42 XEQ "GET"	
43 1152	
44 ST+ 88	
45 39.5	
46 STO 89	
47 055.058	
48 STO 87	
49 XEQ "GET"	
	Prints headings for data summary.
	}
	Finds 8-hour heave rates during first freeze on tape cassette.
	}
	Finds 16-hour heave rates during first freeze.

50 2808		
51 ST+ 88	}	Finds 8-hour heave rates, second freeze.
52 88		
53 STO 89		
54 059.062		
55 STO 87		
56 XEQ "GET"	}	Finds 16-hour heave rates, second freeze.
57 1152		
58 ST+ 88		
59 88		
60 STO 89		
61 063.066	}	
62 STO 87		
63 XEQ "GET"		
64 GTO 03		
65+LBL "GET"		
66 CLA	}	
67 ARCL 00		
68 RCL 88		
69 6		
70 +		
71 SEEKR	}	Subroutine to read data from tape.
72 10.010		
73 READRX		
74 RCL 10		
75 RCL 89		
76 X<Y?	}	
77 GTO 11		
78 72		
79 ST+ 88		
80 GTO "GET"		
81+LBL 11	}	
82 RCL 88		
83 52		
84 +		
85 SEEKR		
86 RCL 87	}	Counters for freeze-thaw cycle.
87 READRX		
88 RTN		
89+LBL 03		
90 FIX 1		
91 - 1 -	}	Counters.
92 ASTO 97		
93 - 2 -		
94 ASTO 98		
95 051.06604		
96 STO 90	}	
97 001.00401		
98 STO 99		

99*LBL 09
100 RCL 90
101 STO 95
102 097.09801
103 STO 96
104 CLA
105 ARCL IND 99
106*LBL 06
107 ARCL IND 96
108 ACA
109 CLA
110 2
111 SKPCHR
112 RCL IND 95
113 ACX
114 2
115 SKPCHR
116 ISG 95
117 GTO 02
118 GTO 05
119*LBL 02
120 RCL IND 95
121 ACX
122 ADV
123 ISG 95
124 GTO 02
125 GTO 05
126*LBL 02
127 ISG 96
128 GTO 06
129*LBL 05
130 CLA
131 PRA
132 001.001
133 ST+ 90
134 ISG 99
135 GTO 09
136*LBL 07
137 END

Prints summary data.

APPENDIX D: DATA SHEETS FOR RECORDING AND PRESENTING RESULTS

FREEZE-THAW SAMPLE PREPARATION DATA SHEET

Series No. _____ Material _____ Date _____
Sample No. _____ Specific Gravity (G_s) _____ Technician _____

Sample Specifications

Max. particle size _____ mm
% finer than .075 mm _____ %
% finer than .020 mm _____ %
Dry density _____ $\frac{gm}{cc}$ _____ $\frac{lb}{ft^3}$
Water content _____ %

Compaction Mode

No. of layers _____
Height of layers _____
Blows per layer _____
Type of hammer _____
Weight of hammer _____

Compaction Data

Wt. of mold (rings + membrane + disk) = _____ gm. Volume of mold, $V_r = 2555$ cc
Wt. of mold + wet soil = _____ gm.
Wt. of wet soil = _____ gm.
Wet unit weight, $\gamma_t = \frac{W_{wet}}{V_r}$ = _____ $\frac{gm}{cc}$ _____ $\frac{lb}{ft^3}$

Water content of compacted soil

tare no. _____
Wt. of tare, W_t _____ gm.
Wt. of tare + wet soil, W_{t+s+w} _____ gm.
Wt. of tare + dry soil, W_{t+s} _____ gm.
Wt. of water, W_w _____ gm.
Wt. of dry soil, W_s _____ gm.
Water content, w _____ %

} from 100 gram sample

Dry unit weight, γ_d _____ $\frac{gm}{cc}$ _____ $\frac{lb}{ft^3}$

Sample Properties

Vol. of solids, $V_s = \gamma_d / (G_s \cdot \gamma_w)$ _____ cc Saturation, $S = w \cdot G_s / e =$ _____ %
Vol. of voids, $V_v = 1 - V_s$ _____ cc
Void ratio, $e = V_v / V_s$ _____
Porosity, $n = V_v \cdot 100$ _____ %

After Freeze-Thaw or Saturation

Slice No	Thickness mm	Tare No	W_t gm	W_{t+s+w} gm	W_{t+s} gm	W_w gm	W_s gm	w %
1								
2								
3								
4								
5								
6								

Note: 1) to determine the degree of saturation after the saturation procedure, a separate sample must be used

FREEZE-THAW TEST RESULTS

SERIES NO _____
 SAMPLE NO _____
 COMPACTION PLANTIES _____
 Water Content % _____
 Dry Density g/cc _____
 Porosity % _____
 void Ratio _____
 Degree of Saturation % _____



Freezing Point Depression _____ °C

	Before Freezing	After Thawing
CHR, %		
w, %		

TIME	FAST HEAVE 1 st Freeze	HEAVE RATE, mm/day	2 nd Freeze
1-hour			
16-hour			

Frost Susceptibility	Heave Rate mm/day	Thawing %
Neg	< 1	> 20
VL	1-2	20-15
L	2-4	15-10
M	4-8	10-5
H	8-16	5-2
VH	> 16	< 2

* Circle frost susceptibility



DATE _____ TECHNICIAN _____

END

6-87

DTIC